HEWLETT hp PACKARD

Model 4942A

Transmission Impairment Measuring Set



Operating Instructions

PLEASE NOTE

FAILURE TO RETURN THIS MANUAL WILL RESULT IN A BILLING CHARGE OF **$25.00**.

PLEASE INCLUDE MANUAL AND ACCESSORIES WHEN RETURNING EQUIPMENT.

Leasametric

CERTIFICATION

Hewlett-Packard Company certifies that this instrument met its published specifications at the time of shipment from the factory. Hewlett-Packard Company further certifies that its calibration measurements are traceable to the United States National Bureau of Standards, to the extent allowed by the Bureau's calibration facility, and to the calibration facilities of other International Standards Organization members.

WARRANTY AND ASSISTANCE

This Hewlett-Packard product is warranted against defects in materials and workmanship for a period of one year from the date of shipment. Hewlett-Packard will, at its option, repair or replace products which prove to be defective during the warranty period provided they are returned to Hewlett-Packard, and provided the preventive maintenance procedures in the Operating and Service Manual are followed. Repairs necessitated by misuse of the product are not covered by this warranty. NO OTHER WARRANTIES ARE EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. HEWLETT-PACKARD IS NOT LIABLE FOR CONSEQUENTIAL DAMAGES.

Service contracts or customer assistance agreements are available for Hewlett-Packard products.

For any assistance, contact your nearest Hewlett-Packard Sales and Service Office. Addresses are provided at the back of this manual.

OPERATING INSTRUCTIONS

TRANSMISSION IMPAIRMENT MEASURING SET

Model 4942A
All Serial Numbers

T A
LIBRARY
COPY NO. 603

© Hewlett-Packard Company 1976
690 E. Middlefield Road, Mountain View, CA. 94042 U.S.A.

04942-90001

PRINTED: MAY 1976

SECTION I
INTRODUCTION

SECTION II
DESCRIPTION OF CONTROLS,

SECTION III
'ETUP AND TURN ON PROCEDURE

DESCRIPTION OF CONTROLS, CONNECTORS, AND INDICATORS



DESCRIPTION OF CONTROLS, CONNECTORS, AND INDICATORS

(1) **Power Cord Receptacle and Fuse.** 117V ac (±10%) 60 Hz power is applied to test set through male power cord receptacle, located on rear of test set. AC line fusing is provided by a 0.75 Amp (SB) fuse located in the fuse holder next to the power cord receptacle. WARNING: ALWAYS CONNECT POWER CORD TO A PROPERLY GROUNDED 3-WIRE POWER OUTLET.

(2) **POWER Switch.** Switches test set ac operating power ON and OFF.

(3) **RCV-TRMT Jacks.** A two position toggle switch is used to reverse connections of the left and right jack fields. When switch is in up position, the left jacks are connected for RCV (receive) and the right jacks for TRMT (transmit). When switch is down, connections are reversed. Dot lamps indicate functions of respective jack fields. Connections can be made either to the 310 jacks, or to the TIP and RING binding posts, which are multipled. The left jack field should always be used for 2-wire wet transmit and receive connections; the right field for 2-wire dry connections. Both left and right jack fields are used for 4-wire connections.

(4) **SETUP CONTROLS.**

NORMAL TEST – DIAL/TALK Switch. In NORMAL TEST position the selected TRMT jack is connected to the test set's transmitter circuitry, but not to the DIAL connectors. In DIAL/TALK position the TRMT jack is connected to the DIAL connectors, but not to the transmitter circuitry.

TEST WITHOUT HOLD – TEST WITH HOLD Switch. In TEST WITHOUT HOLD position the test set holding circuit is disconnected from the RCV-TRMT jacks. In TEST WITH HOLD position the holding circuit is connected across TIP and RING of the left jack field to hold 2-wire wet (DDD) circuits while testing.

TALK BATTERY ON – TALK BATTERY OFF Switch. In TALK BATTERY ON position the test set provides the necessary talk battery to the DIAL terminals to talk on dry circuits with a lineman's handset. In TALK BATTERY OFF position, talk battery must be supplied by the circuit under test if talking is desired.

TERM – BRIDGE RECEIVE Switch. In TERM position the test set provides a termination on both the RCV AND TRMT circuits. The desired terminating impedance must be selected with the 600-900 switch. In BRIDGE-RECEIVE position the receiving test set is bridged across the circuit under test, which must be terminated with other equipment. NOTE: When using BRIDGE RECEIVE it is still necessary to select the proper impedance of the line under test with the 600-900 switch in order to normalize the measurements.

600-900 Switch. The 600Ω or 900Ω termination must be selected to match the characteristic impedance of the line under test. When operating in TERM mode, both the TRMT and RCV circuits are terminated in the selected impedance. When operating in BRIDGE RECEIVE mode, the TRMT circuit is still terminated in the selected impedance and the RCV circuit is bridged by more than 45 kΩ. The selection also normalizes level measurements for the respective impedances.

(continued on next page)

NO SF SKIP – SF SKIP Switch. In NO SF SKIP position the test set will transmit all selected frequencies. In SF SKIP position the test set will not transmit any frequencies between 2450 Hz and 2750 Hz. This feature prevents the circuit under test from being disconnected by SF signaling units on the dial-up network.

NORMAL TEST – SELF CHECK Switch. In NORMAL TEST position the test set performs normal testing. In SELF CHECK position proper operation of the test set can be verified by performing the procedures given in the SELF CHECK section of this manual.

(5) **DIAL Connectors.** Provides connections for a lineman's handset (butt-in). The terminals are connected to the selected TRMT jack when the DIAL/TALK mode is selected.

(6) **Digital Displays.** Two digital displays provide quantitative information and measurement units for all measurements. Ranging is automatic, and polarity and decimal points are automatically displayed when appropriate. Up to two parameters can be displayed simultaneously. The displays also indicate underrange and overrange conditions. Display of only a (–) sign indicates underrange. Display of only a (+) sign indicates overrange.

(7) **DISPLAY Switches.**

TRMT – RCV Switch. Selects either the transmitted or received information to be displayed.

LEVEL – DELAY Switch. Used in ENVELOPE DELAY measurements to display either level (DBM) or delay (MICRO SEC) information.

(8) **MEASUREMENT Switch.** Programs the test set to perform the selected measurement. For a detailed procedure describing the use of each MEASUREMENT switch position, see the appropriate section of this manual.

LEVEL ZERO Switch. Used in LEVEL & FREQUENCY mode to establish a zero dB reference. All subsequent measurements will be made in dB relative to this reference. If this switch is not operated, measurements will be in absolute dBm. NOTE: If LEVEL ZERO switch has been actuated and it is desired to make an absolute dBm measurement, momentarily rotate MEASUREMENT switch to another position, then back to LEVEL & FREQUENCY again.

DELAY ZERO Switch. Used in ENVELOPE DELAY mode to establish a zero microsecond delay reference. All subsequent envelope delay measurements will be relative to this reference.

(9) **LINE MONITOR Speaker and VOLUME Control.** Permits listening to the circuit under test, or the test set transmitter. The DISPLAY TRMT – RCV switch determines whether the transmitted or received signal is being monitored. The speaker output is an amplified reproduction of signals on the circuit (except in C-MESSAGE NOISE mode, which produces a C-weighted output). Speaker output can be controlled with the VOLUME control.

(10) **TRANSMITTER Controls.**

MANUAL – STEP 100 HZ Switch. In MANUAL position frequency is continuously variable from 200 Hz to 3950 Hz by adjusting the FREQUENCY control. In STEP 100 HZ position frequency is manually stepped in 100 HZ increments from 204 Hz to 3904 Hz by depressing the UP and DOWN pushbuttons.

OUTPUT LEVEL Control. Varies transmitter output level continuously from –39 dBm to +10 dBm. Output level is displayed on left display.

(11) **IMPULSE NOISE Controls.**

THRESHOLD DBRNC Switches. Sets the desired threshold above which impulse noise peaks will be totalized on the display. The threshold is adjustable from 30 to 109 dBrnC.

5 MIN – 15 MIN – NONSTOP Count Time Switch. Selects length of time for which impulse noise is counted. Counting is stopped automatically when either the 5 MIN or 15 MIN positions are selected. Counting must be stopped manually with the STOP – START/RESET switch when the NONSTOP position is selected.

STOP – START/RESET Switch. Impulse noise counting is stopped and total is held on display when switch is momentarily held in STOP position. All previous counts are reset to zero on display and new counting interval is initiated when switch is momentarily held in START/RESET position.

(12) **REMOTE Switches.**

MASTER TO SLAVE – SLAVE TO MASTER Switch. Selects transmission path to be tested. Selecting the MASTER TO SLAVE position will cause the circuit connected to the TRMT jack at the MASTER unit to be tested. Selecting the SLAVE TO MASTER position will cause the circuit connected to the RCV jack at the MASTER unit to be tested. The dot lamp associated with the respective position indicates that the MASTER unit has achieved control of the SLAVE unit. The lamp should light within 10 seconds after the NORMAL – MASTER – SLAVE switches are properly positioned on both the MASTER and SLAVE units.

NORMAL – MASTER – SLAVE Switch. In NORMAL position all controls are under manual control. The test set can be operated manually with other compatible test sets. In MASTER position the unit is in remote control of the SLAVE unit for all MEASUREMENT functions. In SLAVE position the unit is remotely controlled by the MASTER unit for all MEASUREMENT functions.

(13) **DELAY Switch.** Used in ENVELOPE DELAY mode to determine whether the test set is to measure envelope delay (NORM), or to retransmit the envelope delay signal from the far-end of the circuit (REPEAT). This control is not used during MASTER-SLAVE operation.

(14) **HP-IB Connector (Optional).** Connections to Hewlett-Packard Interface Bus for controlling the Model 4942A with a calculator or computer. Refer to 4942A Operating and Service Manual for complete description and installation instructions for HP-IB.

SETUP AND TURN ON



SETUP AND TURN ON

1. Connect power cord to receptacle on rear of test set and to 117 volts, 60 Hz ac power line.
2. Set POWER switch to ON to apply power to test set.
3. Set SETUP CONTROLS switch to BRIDGE RECEIVE if test set is to be bridged across receive line. Set to TERM if test set is to be used as termination on receive line.
4. Set SETUP CONTROLS switch to 600 or 900 to match impedance of lines under test.
5. Set SETUP CONTROLS switch to SF SKIP if transmitting over a dial-up network and single frequency (SF) signaling units are on the network.
6. Set SETUP CONTROLS switch to NORMAL TEST. Refer to SELF CHECK procedure if desired to verify test set performance.

NOTE

The SELF CHECK procedure should be performed periodically to verify performance of the test set. SELF CHECK is recommended before transporting the test set to a remote testing site; or whenever there is any doubt about transmission measurement results.

7. Set SETUP CONTROLS switch to TEST WITHOUT HOLD.
8. Turn OUTPUT LEVEL control full counterclockwise.
9. Position RCV-TRMT jacks switch to select the receive or transmit function for the left jack field. Connect transmit and receive lines (if both are required) to the appropriate jacks. Refer to DIAL, TALK, LISTEN, & HOLD procedures if dialing, talking, listening, or holding is desired on the lines under test.

NOTE

A 4-wire circuit is required to operate in the remote MASTER-SLAVE mode. If desired to test a 2-wire circuit in the remote MASTER-SLAVE mode, a second 2-wire circuit must be provided.

10. If remote MASTER-SLAVE operation is desired, refer to SLAVE SETUP or MASTER OPERATION procedures.
11. Select desired MEASUREMENT mode and refer to appropriate measurement procedure.

SELF-CHECK


4942A TRANSMISSION IMPAIRMENT MEASURING SET
HEWLETT · PACKARD
DISPLAY
TRMT
DELAY
RCV
LEVEL
+1888.8
SLAVE
MICRO SEC
DBM
DB
DBRNC
8888
HP · IB
RCV HZ
COUNTS
TRMT HZ
IN PROCESS
POWER
ON
OFF
IMPULSE NOISE
5
6
THRESHOLD DBRNC
5 MIN
15 MIN
NON-STOP
STOP
START
RESET
REMOTE
MASTER TO SLAVE
SLAVE TO MASTER
NORMAL
MASTER
SLAVE
DELAY
NORMAL
REPEAT
TRANSMITTER
FREQUENCY
OUTPUT LEVEL
FINE
MANUAL
DOWN
STEP
100 HZ
UP
RCV
TRMT
TRMT
TIP
RCV
TIP
HOLD
RING
RING
310
310
DIAL
MEASUREMENT
NOISE-WITH-TONE
C-MESSAGE NOISE
LEVEL & FREQUENCY
SIGNAL-TO-NOISE
IMPULSE NOISE
ENVELOPE DELAY
LEVEL ZERO
LINE LOOP BACK
DELAY ZERO
LINE MONITOR
VOLUME
SETUP CONTROLS
NORMAL TEST
DIAL TALK
TEST WITHOUT HOLD
TEST WITH HOLD
TALK BATTERY ON
TALK BATTERY OFF
TERM
BRIDGE RECEIVE
600
900
NO SF SKIP
SF SKIP
NORMAL TEST
SELF CHECK

SELF-CHECK

NOTE

The SELF CHECK routine automatically makes an operational check of the test set, including its ability to operate in MASTER and SLAVE modes. The test set will automatically step through the SELF CHECK routine and should produce indications at each step as indicated below. At the end of the SELF CHECK routine, the display will indicate PASS if all checks are within specifications. If any steps fail to pass, the display will indicate failure codes at the end of the routine for those steps that fail to pass. A list of SELF CHECK failure codes, and their meanings are given at the end of this procedure.

The SELF CHECK procedure should be performed periodically to verify performance of the test set. SELF CHECK is recommended before transporting the test set to a remote testing site; or whenever there is any doubt about transmission measurement results.

1. PRELIMINARY SETUP
   a. Disconnect test set from on-line testing.
   b. Switch POWER ON.
   c. Loop TRMT jack to RCV jack. Operate RCV/TRMT jack field switch and observe that corresponding dot lamps light.
   d. Set all SETUP CONTROLS Switches to "up" positions.
   e. Set REMOTE Switch to NORMAL or MASTER.
   f. Set NORMAL TEST – SELF CHECK Switch to SELF CHECK.

2. STEP 1: DISPLAY AND ANNUNCIATOR CHECKS
   a. Observe that left display indicates +1888.8 and that right display indicates 8888. Observe that all numerical segments are present and evenly illuminated.
   b. Observe that all display annunciators are on and evenly illuminated.
   c. Observe that MASTER TO SLAVE and SLAVE TO MASTER dot lights are on.

NOTE

It is not necessary to observe the following test routine unless it is desired to analyze a specific problem with the test set. SELF CHECK status will be displayed at the end of the routine.

3. STEPS 2-4: LEVEL & FREQUENCY CHECKS
   a. Left display should indicate +0.0 DBM (±0.3 dBm). Right display should indicate 204 RCV HZ (±2 Hz).
   b. Left display should indicate +0.0 DBM (±0.3 dBm). Right display should indicate 1004 RCV HZ (±2 Hz).
   c. Left display should indicate +0.0 DBM (±0.3 dBm). Right display should indicate 3904 RCV HZ (±2 Hz).

4. STEPS 5-7: C-MESSAGE FILTER CHECKS
   a. Left display should indicate –16.0 DBM (±1.0 dBm). Right display should indicate 304 RCV HZ (±2 Hz).
   b. Left display should indicate +0.0 DBM (±0.3 dBm). Right display should indicate 1004 RCV HZ (±2 Hz).
   c. Left display should indicate –2.5 DBM (±1.0 dBm). Right display should indicate 3004 RCV HZ (±2 Hz).

(continued on next page)

5. STEP 8: NOISE-WITH-TONE NOTCH CHECK

   a. Left display should indicate less than -50 DBM (algebraically). Right display should indicate 1004 RCV HZ (±2 Hz).

6. STEP 9: IMPULSE NOISE CHECK

   a. Right display should indicate 70 COUNTS (±4 Counts).

7. STEP 10: ENVELOPE DELAY CHECK

   a. Left display should reset to 0 MICROSECONDS, then indicate 3000 MICROSECONDS (±10μS). Right display should indicate 1804 RCV HZ (±2 Hz).

8. STEP 11: SELF CHECK STATUS DISPLAY

   a. If all SELF CHECK tests are within specifications the display will indicate PASS until the NORMAL TEST – SELF CHECK Switch is returned to the NORMAL TEST position. The test set has passed all of the above visible tests, in addition to ENVELOPE DELAY response time and a complete check of the modem used for MASTER – SLAVE operation.

   b. If the test set fails to pass any of the above tests, failure codes will be displayed indicating the tests that have failed. These codes will be displayed sequentially until the NORMAL TEST – SELF CHECK Switch is returned to the NORMAL TEST position. Following are interpretations of the SELF CHECK failure codes that can be displayed:

CODE	MESSAGE
H20	Level out of tolerance at 204 Hz (STEP 2)
H21	Level out of tolerance at 1004 Hz (STEP 3)
H22	Level out of tolerance at 3904 Hz (STEP 4)
H30	C-Message filter out of tolerance at 304 Hz (STEP 5)
H31	C-Message filter out of tolerance at 1004 Hz (STEP 6)
H32	C-Message filter out of tolerance at 3004 Hz (STEP 7)
H33	Noise-With-Tone notch out of tolerance (STEP 8)
H34	Impulse Noise counts out of tolerance (STEP 9)
H40	Frequency out of tolerance at 204 Hz, 1004 Hz, or 3904 Hz (STEPS 2-4)
H70	Envelope Delay response time out of tolerance (STEP 10)
H71	Envelope Delay accuracy out of tolerance (STEP 10)
H80, H81, H82, H83	Test set modem does not pass SELF CHECK (NOTE: Failure of the modem affects only MASTER – SLAVE operation. Normal operation is not affected).

(continued on next page)

9. SELF CHECK – MODEM ONLY.

If a quick SELF CHECK of only the modem is desired, the following procedure can be used:

a. Perform PRELIMINARY SETUP procedures (a) through (e).

b. Hold DELAY ZERO Switch in "down" position while setting NORMAL TEST – SELF CHECK Switch to SELF CHECK. Release DELAY ZERO Switch.

c. If modem passes SELF CHECK, display will immediately indicate PASS. Refer to failure codes, above, if failure code is displayed.

CONDITION CODES

Under certain conditions, the 4942A will abort or fail to achieve its normal display and indicate a "condition code" in the display. Following is a list of condition codes that can occur, their messages, probable causes, and recommended remedial actions to clear the condition. (Also refer to SELF CHECK procedure for listing of SELF CHECK failure codes).

CONDITION CODE	MESSAGE	PROBABLE CAUSES	RECOMMENDED ACTIONS
H-00	Front panel controls changed while MASTER attempting to achieve control over SLAVE.	1. Operator error.	1. Do not touch controls until dot light illuminates.
H-01	No data carrier received from SLAVE.	1. SLAVE OUTPUT LEVEL set too low	1. Check SLAVE OUTPUT LEVEL.
		2. Excessive circuit loss.	2. Check that MASTER receives at least −40 dBm.
		3. 4942A problem.	3. Perform SELF CHECK on MASTER and SLAVE units. Return test set for repair if necessary.
H-02	No data information received from SLAVE.	1. Excessive noise on circuit.	1. Check circuit noise.
		2. 4942A problem.	2. Perform SELF CHECK on SLAVE unit. Return test set for repair if necessary.
H-03	Data errors.	1. Excessive noise on circuit.	1. Check circuit noise.
		2. 4942A problem.	2. Perform SELF CHECK on MASTER unit. Return test set for repair if necessary.
H-04	Data errors.	1. 4942A problem.	1. Perform SELF CHECK on MASTER and SLAVE units. Return test set for repair if necessary.
H-05	Inappropriate response to MASTER-SLAVE commands.	1. 4942A problem.	1. Perform SELF CHECK on MASTER and SLAVE units. Return test set for repair if necessary.
		2. Distortion on circuit due to high level or circuit malfunction.	2. Check MASTER and SLAVE OUTPUT LEVELS.
H-06	SLAVE not responding to MASTER command.	1. MASTER OUTPUT LEVEL set too low.	1. Check MASTER OUTPUT LEVEL.
		2. Excessive circuit loss.	2. Check that SLAVE receives at least −40 dBm.
		3. Excessive noise on circuit.	3. Check circuit noise.
		4. 4942A problem.	4. Perform SELF CHECK on MASTER and SLAVE units. Return test set for repair if necessary.
H-07	Incompatible SLAVE measurement.	1. SLAVE can make requested measurement only in LINE LOOP BACK.	1. SLAVE must be compatible with MASTER (or it aborts to LINE LOOP BACK mode for measurements not available in SLAVE unit).

CONDITION CODE	MESSAGE	PROBABLE CAUSES	RECOMMENDED ACTIONS
H-08	Invalid command.	1. MASTER MEASUREMENT Switch set to LINE LOOP BACK. 2. 4942A problem.	1. Set MASTER MEASUREMENT Switch to valid position. 2. Perform SELF CHECK on MASTER unit. Return test set for repair if necessary.
H-09	No data received when expected.	1. Circuit dropout. 2. SLAVE OUTPUT CONTROL moved during data transmission. 3. 4942A problem.	1. Check circuit; re-run test. 2. Do not touch SLAVE OUTPUT CONTROL while measurement in progress. 3. Perform SELF CHECK on MASTER and SLAVE units. Return test set for repair if necessary.
H-10	SLAVE Underrange; test Level or Noise below range capability.	1. Normal condition.	1. None
H-11	MASTER receives incorrect response.	1. RCV-TRMT Switch changed during data transmission. 2. 4942A problem.	1. Do not touch RCV-TRMT Switch while measurement in progress. 2. Perform SELF CHECK on MASTER and SLAVE units. Return test set for repair if necessary.
H-12	IMPULSE NOISE accumulator overflow.	1. IMPULSE NOISE exceeded 9999 COUNTS.	1. Use shorter counting interval.
H-13	SLAVE aborted control of MASTER.	1. SLAVE REMOTE Switch changed to NORMAL or MASTER during data transmission.	1. Do not touch SLAVE REMOTE Switch while measurement in progress.
H-14	Signal dropout >1 Sec. during IMPULSE NOISE measurement.	1. Circuit dropped out carrier.	1. Initiate new test.

DIAL, TALK, LISTEN, AND HOLD



DIAL, TALK, LISTEN, AND HOLD

1. Perform SETUP AND TURN ON procedure through step 9.
2. Connect lineman's handset (butt-in) to DIAL connectors.
3. Refer to table below for proper hookup and control settings.

NOTE

When selecting the SETUP CONTROLS-NORMAL TEST switch on 2-wire wet (DDD) line, make sure the SETUP CONTROLS switch is in the TEST WITH HOLD position before switching to NORMAL TEST. Failure to do so will cause the dial-up connection to be lost.

4. To return to talk or listen mode after normal tests are in progress, set SETUP CONTROLS switch to DIAL/TALK. Set RCV-TRMT jacks switch as indicated for 2-wire connection.

HOOKUP AND SETUP CONTROL SETTINGS FOR DIALING, TALKING, LISTENING, HOLDING AND TESTING

MODE	CIRCUIT		
	2-Wire Wet (DDD)	2-Wire Dry (DAA)	4-Wire Dry
HOOKUP	Transmit line connected to left RECEIVE/TRANSMIT JACKS	Transmit line connected to right RECEIVE/TRANSMIT JACKS	Transmit line connected to either RECEIVE/TRANSMIT JACKS
DIAL	DIAL/TALK; TALK BATTERY OFF; TEST WITHOUT HOLD; LEFT JACK TO TRMT (Dial with butt-in)		
TALK	DIAL/TALK; TALK BATTERY OFF; TEST WITH HOLD; LEFT JACK TO TRMT (Talk through butt-in)	DIAL/TALK; TALK BATTERY ON; TEST WITHOUT HOLD; RIGHT JACK TO TRMT (Talk through butt-in)	DIAL/TALK; TALK BATTERY ON; TEST WITHOUT HOLD (Talk through butt-in)
LISTEN	DIAL/TALK; TALK BATTERY OFF; TEST WITH HOLD; LEFT JACK TO TRMT (Listen through butt-in)	DIAL/TALK; TALK BATTERY ON; TEST WITHOUT HOLD; RIGHT JACK TO TRMT (Listen through butt-in)	Adjust LINE MONITOR as required (Listen through LINE MONITOR speaker)
TEST	TALK BATTERY OFF; TEST WITH HOLD; NORMAL TEST, (Throw TEST WITH HOLD switch **before** throwing NORMAL TEST switch); LEFT JACK TO RCV IF RECEIVE TEST SET	TALK BATTERY ON; TEST WITHOUT HOLD; NORMAL TEST; RIGHT JACK TO RCV IF RECEIVE TEST SET	TALK BATTERY ON; TEST WITHOUT HOLD; NORMAL TEST

NORMAL OPERATION PROCEDURES

LEVEL AND FREQUENCY NORMAL TRANSMITTER




TRANSMITTER
RECEIVER
TRANSMITS VARIABLE FREQUENCIES 204 Hz – 3904 Hz AT DATA LEVEL.
RECEIVES VARIABLE FREQUENCIES 204 – 3904 Hz. MEASURES dB LEVEL OR dBm LOSS.
TRMT
CIRCUIT UNDER TEST
RCV

LEVEL AND FREQUENCY NORMAL TRANSMITTER

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to LEVEL & FREQUENCY.
3. Set DISPLAY Switch to TRMT.
4. Set TRANSMITTER Switch to STEP 100 HZ.
5. If SF signaling units are used in the network under test, set NO SF SKIP – SF SKIP Switch to SF SKIP. This mode automatically blanks the transmitter output so that frequencies between 2450 Hz and 2750 Hz cannot be transmitted.
6. Adjust transmit frequency to 1004 Hz using TRANSMITTER UP – DOWN Pushbuttons. Observe TRMT HZ in right display.
7. Adjust OUTPUT LEVEL Control for "data Level". Observe DBM level in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Transmission Level Point (TLP). For example, if the TLP is –16 dB, the Data Level would be –29 dBm. Therefore, an output level of –29 dBm would be applied in this case.

8. When requested by NORMAL RECEIVER Operator, transmit agreed upon test frequencies. When in STEP 100 HZ mode, frequencies of 204 Hz to 3904 Hz can be selected. Frequencies other than those at the step points can be selected by setting the TRANSMITTER Switch to MANUAL and adjusting the FREQUENCY Control.

See next pages for NORMAL RECEIVER procedures.

LEVEL & FREQUENCY NORMAL RECEIVER




TRANSMITTER
TRANSMITS VARIABLE FREQUENCIES 204 Hz – 3904 Hz AT DATA LEVEL.
RECEIVER
RECEIVES VARIABLE FREQUENCIES 204 – 3904 Hz. MEASURES dB LEVEL OR dBm LOSS
TRMT
CIRCUIT UNDER TEST
RCV

LEVEL AND FREQUENCY NORMAL RECEIVER

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to LEVEL & FREQUENCY.
3. Set DISPLAY Switch to RCV.

1000 HZ LOSS MEASUREMENT

4. Instruct NORMAL TRANSMITTER Operator to send 1004 Hz tone.
5. Observe RCV HZ (nominally 1004 Hz) in right display and received DBM level in left display.

FREQUENCY SHIFT MEASUREMENT

6. Observe RCV HZ while communicating with NORMAL TRANSMITTER Operator. Compare any difference between the transmitted and received frequency.

NOTE

The transmitting test set must transmit a frequency known to within ±0.5 Hz, such as another Hewlett-Packard Transmission Impairment Measuring Set.

ATTENUATION DISTORTION MEASUREMENT

7. Momentarily hold down LEVEL ZERO Switch. This establishes a 0 dB reference at the reference frequency (1004 Hz).
8. Observe RCV HZ in right display and DB relative loss in left display, as agreed upon frequencies are transmitted. +DB indicates more loss and –DB indicates less loss, relative to the reference frequency.

NOTE

Attenuation Distortion measurements can also be made in absolute dBm. The test set is automatically in the dBm mode until the LEVEL ZERO Switch is operated. To return the test set to the dBm mode, momentarily rotate MEASUREMENT Switch to another position, then back to LEVEL & FREQUENCY again.

C-MESSAGE NOISE NORMAL TRANSMITTER





C-MESSAGE NOISE NORMAL TRANSMITTER

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to C-MESSAGE NOISE. This provides the TRMT jack with a quiet termination.

See next pages for NORMAL RECEIVER procedures.

C-MESSAGE NOISE NORMAL RECEIVER





C-MESSAGE NOISE NORMAL RECEIVER

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to C-MESSAGE NOISE.
3. Set DISPLAY Switch to RCV.
4. Observe DBRNC noise level in left display.

SINGLE FREQUENCY INTERFERENCE CHECK

5. Turn on LINE MONITOR by adjusting VOLUME control until desired loudness is obtained in speaker. Listen for any predominant tone which will indicate a potential single frequency interference problem.

NOISE-WITH-TONE NORMAL TRANSMITTER





NOISE-WITH-TONE NORMAL TRANSMITTER

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to NOISE-WITH-TONE.
3. Set DISPLAY Switch to TRMT.
4. Observe TRMT HZ in right display. Verify that 1004 Hz is being transmitted.
5. Adjust OUTPUT LEVEL Control for "Data Level". Observe DBM level in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Transmission Level Point (TLP). For example, if the TLP is –16 dB, the Data Level would be –29 dBm. Therefore, an output level of –29 dBm would be applied in this case.

See next pages for NORMAL RECEIVER procedures.

NOISE-WITH-TONE NORMAL RECEIVER





NOISE-WITH-TONE NORMAL RECEIVER

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to NOISE-WITH-TONE.
3. Set DISPLAY Switch to RCV.
4. Observe RCV HZ in right display. Verify that received frequency is between 995 Hz and 1025 Hz.
5. Turn on LINE MONITOR by adjusting VOLUME control until desired loudness is obtained in speaker. Listen for any predominant tone which will indicate a potential single frequency interference problem.
6. Observe DBRNC noise level in left display.

SIGNAL-TO-NOISE NORMAL TRANSMITTER





SIGNAL-TO-NOISE NORMAL TRANSMITTER

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to SIGNAL-TO-NOISE.
3. Set DISPLAY Switch to TRMT.
4. Observe TRMT HZ in right display. Verify that 1004 Hz is being transmitted.
5. Adjust OUTPUT LEVEL Control for "Data Level". Observe DBM level in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Transmission Level Point (TLP). For example, if the TLP is -16 dB, the Data Level would be -29 dBm. Therefore, an output level of -29 dBm would be applied in this case.

See next pages for NORMAL RECEIVER procedures.

SIGNAL-TO-NOISE NORMAL RECEIVER





SIGNAL-TO-NOISE NORMAL RECEIVER

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to SIGNAL-TO-NOISE.
3. Set DISPLAY Switch to RCV.
4. Observe RCV HZ in right display. Verify that received frequency is between 995 Hz and 1025 Hz.
5. Observe DB signal-to-noise ratio (S+N/N) in left display.

IMPULSE NOISE NORMAL TRANSMITTER





IMPULSE NOISE NORMAL TRANSMITTER

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to IMPULSE NOISE.
3. Set DISPLAY Switch to TRMT.
4. Observe TRMT HZ in right display. Verify that 1004 Hz is being transmitted.
5. Adjust OUTPUT LEVEL Control for "Data Level". Observe DBM in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Transmission Level Point (TLP). For example, if the TLP is –16 dB, the Data Level would be –29 dBm. Therefore, an output level of –29 dBm would be applied in this case.

See next pages for NORMAL RECEIVER procedures.

IMPULSE NOISE NORMAL RECEIVER





ENVELOPE DELAY-RETURN REFERENCE NORMAL TEST SET

1. Set REMOTE Switch to NORMAL.
2. Connect pair to be tested to TRMT Jack. Connect Return Reference pair to RCV Jack.
3. Set MEASUREMENT Switch to ENVELOPE DELAY.
4. Set DISPLAY Switches to TRMT and LEVEL.
5. Set DELAY Switch to NORMAL.
6. Adjust OUTPUT LEVEL Control for "Data Level". Observe DBM in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Transmission Level Point (TLP). For example, if the TLP is –16 dB, the Data Level would be –29 dBm. Therefore, an output level of –29 dBm would be applied in this case.

7. When *Repeat Test Set* operator has completed *his Step 7,* set DISPLAY Switch to RCV.
8. Notify *Repeat Test Set* operator that you have completed *your Step 7.*
9. Observe received DBM level in left display. This level must be –40 dBm or greater for valid measurements.
10. Set DISPLAY Switches to TRMT and DELAY.
11. Set TRANSMITTER Switch to STEP 100 HZ.
12. If SF signaling units are used in the network under test, set NO SF SKIP-SF SKIP Switch to SF SKIP. This mode automatically blanks the transmitter output so that frequencies between 2450 Hz and 2750 Hz cannot be transmitted.
13. Adjust transmit frequency to reference frequency (e.g., 1804 Hz, or frequency of minimum delay) using TRANSMITTER UP-DOWN Pushbuttons.
14. Observe ± MICRO SEC in left display. This reading may be very erratic for a few seconds until the loop stabilizes. When the display stabilizes so that only the units and tens digits are changing, momentarily hold down and release DELAY ZERO Switch.

NOTE

This establishes a reference zero at the reference frequency. Typically, this reading will vary ±5 MICRO SEC. However, on very noisy circuits, the variation may be greater. A valid reference zero is established if these variations are evenly distributed above and below zero microseconds.

15. Select desired test frequencies using TRANSMITTER UP-DOWN Pushbuttons. Observe TRMT HZ in right display.
16. At each test frequency, observe ± MICRO SEC envelope delay in left display. If readings vary, observe for an arithmetic mean (average).

See next pages for REPEAT TEST SET procedures.

ENVELOPE DELAY-RETURN REFERENCE REPEAT TEST SET




NORMAL SET
TRANSMITS VARIABLE CARRIER FREQUENCIES 204 Hz – 3904 Hz MODULATED WITH 83-1/3 Hz ON CIRCUIT UNDER TEST. RECEIVES 83-1/3 Hz ON FIXED CARRIER FROM REPEAT SET ON RETURN REF. CIRCUIT CIRCUIT AND MEASURES DELAY
REPEAT SET
RECEIVES VARIABLE CARRIER WITH 83-1/3 Hz MODULATION ON CIRCUIT UNDER TEST. REMODULATES 83-1/3 Hz ON FIXED CARRIER AND TRANSMITS TO NORMAL SET ON RETURN REF. CIRCUIT.
TRMT
CIRCUIT UNDER TEST
RCV
RCV
RETURN REFERENCE CIRCUIT
TRMT

ENVELOPE DELAY-RETURN REFERENCE REPEAT TEST SET

1. Set REMOTE Switch to NORMAL.
2. Connect pair to be tested to RCV Jack. Connect Return Reference pair to TRMT Jack.
3. Set MEASUREMENT Switch to ENVELOPE DELAY.
4. Set DISPLAY Switches to TRMT and LEVEL.
5. Set DELAY Switch to REPEAT.
6. Adjust OUTPUT LEVEL Control for "Data Level". Observe DBM in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Transmission Level Point (TLP). For example, if the TLP is –16 dB, the Data Level would be –29 dBm. Therefore, an output level of –29 dBm would be applied in this case.

7. Set TRANSMITTER Switch to STEP 100 HZ. Adjust transmit frequency to reference frequency (e.g., 1804 Hz, or frequency of minimum delay) using TRANSMITTER UP-DOWN Pushbuttons.
8. Notify *Normal Test Set* operator that you have completed *your Step 7.*
9. When *Normal Test Set* operator notifies you that he has completed *his Step 7,* set DISPLAY Switch to RCV.
10. Monitor DBM received level in left display to be sure it remains –40 dBm or greater throughout the measurements.

ENVELOPE DELAY-FORWARD REFERENCE NORMAL TEST SET




NORMAL SET
REPEAT SET
TRANSMITS FIXED CARRIER MODULATED WITH 83-1/3 Hz ON FORWARD REF. CIRCUIT. RECEIVES VARIABLE CARRIER WITH 83-1/3 Hz MODULATION FROM REPEAT SET ON CIRCUIT UNDER TEST AND MEASURES DELAY.
RECEIVES FIXED CARRIER WITH 83-1/3 Hz MODULATION ON FORWARD REF. CIRCUIT. REMODULATES 83-1/3 Hz ON VARIABLE CARRIER FREQUENCIES 204 Hz–3904 Hz AND TRANSMITS TO NORMAL SET ON CIRCUIT UNDER TEST.
TRMT
FORWARD REFERENCE CIRCUIT
RCV
RCV
CIRCUIT UNDER TEST
TRMT

ENVELOPE DELAY-FORWARD REFERENCE NORMAL TEST SET

1. Set REMOTE Switch to NORMAL.
2. Connect pair to be tested to RCV Jack. Connect Forward Reference pair to TRMT Jack.
3. Set MEASUREMENT Switch to ENVELOPE DELAY.
4. Set DISPLAY Switches to TRMT and LEVEL.
5. Set DELAY Switch to NORMAL.
6. Adjust OUTPUT LEVEL Control for "Data Level". Observe DBM in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Transmission Level Point (TLP). For example, if the TLP is –16 dB, the Data Level would be –29 dBm. Therefore, an output level of –29 dBm would be applied in this case.

7. Set TRANSMITTER Switch to STEP 100 HZ. Adjust transmit frequency to reference frequency (e.g., 1804 Hz, or frequency of minimum delay) using TRANSMITTER UP-DOWN Pushbuttons.
8. When *Repeat Test Set* operator has completed *his Step 9,* set DISPLAY Switch to RCV.
9. Notify *Repeat Test Set* operator that you have completed *your Step 7.*
10. Observe received DBM level in left display. This level must be –40 dBm or greater for valid measurements.
11. Set DISPLAY Switch to DELAY.
12. Observe ± MICRO SEC in left display. This reading may be very erratic for a few seconds until the loop stabilizes. When the display stabilizes so that only the units and tens digits are changing, momentarily hold down and release DELAY ZERO Switch.

NOTE

This establishes a reference zero at the reference frequency. Typically, this reading will vary ±5 MICRO SEC. However, on very noisy circuits, the variation may be greater. A valid reference zero is established if these variations are evenly distributed above and below zero microseconds.

13. Notify *Repeat Test Set* operator to begin sending the agreed upon test frequencies.
14. At each test frequency, observe ± MICRO SEC envelope delay in left display. If readings vary, observe for an arithmetic mean (average). Observe RCV HZ in right display.

See next pages for REPEAT TEST SET procedures.

ENVELOPE DELAY-FORWARD REFERENCE REPEAT TEST SET




NORMAL SET
TRANSMITS FIXED CARRIER MODULATED WITH 83-1/3 Hz ON FORWARD REF. CIRCUIT. RECEIVES VARIABLE CARRIER WITH 83-1/3 Hz MODULATION FROM REPEAT SET ON CIRCUIT UNDER TEST AND MEASURES DELAY.
REPEAT SET
RECEIVES FIXED CARRIER WITH 83-1/3 Hz MODULATION ON FORWARD REF. CIRCUIT. REMODULATES 83-1/3 Hz ON VARIABLE CARRIER FREQUENCIES 204 Hz–3904 Hz AND TRANSMITS TO NORMAL SET ON CIRCUIT UNDER TEST.
TRMT
FORWARD REFERENCE CIRCUIT
RCV
RCV
CIRCUIT UNDER TEST
TRMT

ENVELOPE DELAY-FORWARD REFERENCE REPEAT TEST SET

1. Set REMOTE Switch to NORMAL.
2. Connect pair to be tested to TRMT Jack. Connect Forward Reference pair to RCV Jack.
3. Set MEASUREMENT Switch to ENVELOPE DELAY.
4. Set DISPLAY Switches to TRMT and LEVEL.
5. Set DELAY Switch to REPEAT.
6. Adjust OUTPUT LEVEL Control for "Data Level". Observe DBM level in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Transmission Level Point (TLP). For example, if the TLP is –16 dB, the Data Level would be –29 dBm. Therefore, an output level of – 29 dBm would be applied in this case.

7. Set TRANSMITTER Switch to STEP 100 HZ.
8. If SF signaling units are used on the circuit under test, set NO SF SKIP – SF SKIP Switch to SF SKIP. This mode automatically blanks the transmitter output so that frequencies between 2450 Hz and 2750 Hz cannot be transmitted.
9. Adjust transmit frequency to reference frequency (e.g., 1804 Hz, or frequency of minimum delay) using TRANSMITTER UP-DOWN Pushbuttons.
10. Notify *Normal Test Set* operator that you have completed *your Step 9.*
11. When *Normal Test Set* operator notifies you that he has completed *his Step 7,* set DISPLAY Switch to DELAY.
12. When requested by *Normal Test Set* operator, transmit agreed upon frequencies using TRANSMITTER UP-DOWN Pushbuttons. Observe TRMT HZ in right display.

LINE LOOP BACK





LINE LOOP BACK

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to LEVEL & FREQUENCY.
3. Set DISPLAY Switch to TRMT.
4. Set TRANSMITTER Switch to STEP 100 HZ.
5. Adjust transmit frequency to 1004 Hz using TRANSMITTER UP-DOWN Pushbuttons. Observe TRMT HZ in right display.
6. Adjust OUTPUT LEVEL Control for "Data Level". Observe DBM level in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Tranmission Level Point (TLP). For example, if the TLP is –16 dB, the Data Level would be – 29 dBm. Therefore, an output level of –29 dBm would be applied in this case.

7. Set MEASUREMENT Switch to LINE LOOP BACK. The test set is now operating as a voice frequency repeater, with its output level normalized to Data Level.

MASTER/SLAVE OPERATION PROCEDURES

SLAVE SETUP


4942A TRANSMISSION IMPAIRMENT MEASURING SET
HEWLETT · PACKARD
DISPLAY
TRMT
DELAY
RCV
LEVEL
SLAVE
PROCESS
POWER
ON
OFF
IMPULSE NOISE
5 MIN
15 MIN
NON-STOP
STOP
START
RESET
THRESHOLD DBRNC
REMOTE
MASTER TO SLAVE
SLAVE TO MASTER
NORMAL
MASTER
SLAVE
DELAY
NORMAL
REPEAT
TRANSMITTER
FREQUENCY
OUTPUT LEVEL
FINE
MANUAL
DOWN
STEP 100 HZ
UP
RCV
TRMT
TRMT TIP
RCV TIP
RING
RING
HOLD
310
310
DIAL
MEASUREMENT
NOISE-WITH-TONE
C-MESSAGE NOISE
LEVEL & FREQUENCY
SIGNAL TO-NOISE
IMPULSE NOISE
ENVELOPE DELAY
LEVEL ZERO
LINE LOOP BACK
DELAY ZERO
SETUP CONTROLS
NORMAL TEST
DIAL TALK
TEST WITHOUT HOLD
TEST WITH HOLD
TALK BATTERY ON
TALK BATTERY OFF
TERM
BRIDGE RECEIVE
600
900
NO SF SKIP
SF SKIP
NORMAL TEST
SELF CHECK
LINE MONITOR
VOLUME


MASTER
SLAVE
SLAVE UNIT CONTROLLED BY MASTER UNIT
TRMT
M TO S CIRCUIT UNDER TEST
RCV
RCV
S TO M CIRCUIT UNDER TEST
TRMT

SLAVE SETUP

1. Perform SETUP & TURN ON procedures through Step 9.
2. Set REMOTE Switch to NORMAL.
3. Set MEASUREMENT Switch to LEVEL & FREQUENCY.
4. Set DISPLAY Switch to TRMT.
5. Set TRANSMITTER Switch to STEP 100 HZ.
6. Adjust transmit frequency to 1004 Hz using TRANSMITTER UP-DOWN Pushbuttons. Observe TRMT HZ in right display.
7. Adjust OUTPUT LEVEL for "Data Level". Observe DBM in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Transmission Level Point (TLP). For example, if the TLP is –16 dB, the Data Level would be –29 dBm. Therefore, an output level of –29 dBm would be applied in this case.

8. If IMPULSE NOISE is to be measured, set IMPULSE NOISE Thumbwheel Switches to desired DBRNC THRESHOLD.
9. Set REMOTE Switch to SLAVE. The SLAVE unit is now set up for control by the MASTER unit. If desired, the display annunciators can be observed to determine the progress of the MASTER unit. The following annunciators indicate the mode of the MASTER unit:

LEVEL & FREQUENCY	DBM
C-MESSAGE NOISE	DBRNC
NOISE-WITH-TONE	DBRN and TRMT HZ
SIGNAL-TO-NOISE	DB
IMPULSE NOISE	COUNTS
ENVELOPE DELAY	MICRO SEC

LEVEL AND FREQUENCY MASTER OPERATION




MASTER
SLAVE
MASTER TO SLAVE
MASTER TRANSMITS TEST FREQUENCIES TO SLAVE. SLAVE MEASURES RECEIVED dB OR dBm LEVELS AND TRANSMITS DATA TO MASTER DISPLAY ON OPPOSITE CIRCUIT.
SLAVE TO MASTER
MASTER TRANSMITS COMMANDS TO SLAVE TO TRANSMIT DESIRED TEST FREQUENCIES. MASTER MEASURES AND DISPLAYS RECEIVED dB OR dBm LEVELS.
TRMT
M TO S CIRCUIT UNDER TEST
RCV
RCV
S TO M CIRCUIT UNDER TEST
TRMT

LEVEL AND FREQUENCY MASTER OPERATION

MASTER SETUP

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to LEVEL & FREQUENCY.
3. Set DISPLAY Switch to TRMT.
4. Set TRANSMITTER Switch to STEP 100 HZ.
5. If SF signaling units are used in the network under test, set NO SF SKIP – SF SKIP Switch to SF SKIP. This mode automatically blanks the transmitter output so that frequencies between 2450 Hz and 2750 Hz cannot be transmitted.
6. Adjust transmit frequency to 1004 Hz using TRANSMITTER UP-DOWN Pushbuttons. Observe TRMT HZ in right display.
7. Adjust OUTPUT LEVEL Control for "Data Level". Observe DBM level in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Transmission Level Point (TLP). For example, if the TLP is – 16 dB, the Data Level would be – 29 dBm. Therefore, an output level of – 29 dBm would be applied in this case.

8. Set DISPLAY Switch to RCV.
9. Set REMOTE Switch to MASTER.

MASTER TO SLAVE DIRECTION

10. Set REMOTE Switch to MASTER TO SLAVE. Wait until associated dot light illuminates before proceeding. This dot light should come on within 10 seconds. It indicates that the MASTER unit has achieved control over the SLAVE unit. Observe that SLAVE annunciator is on, indicating that measurements will be made by SLAVE unit.

1000 HZ LOSS MEASUREMENT

11. Observe MASTER generated TRMT HZ (nominally 1004 Hz) in right display. Observe DBM level received by SLAVE unit on left display.

ATTENUATION DISTORTION MEASUREMENT

12. Momentarily hold down LEVEL ZERO Switch. This establishes a 0 dB reference at the reference frequency (1004 Hz).
13. Transmit desired test frequencies using TRANSMITTER UP-DOWN Pushbuttons or MANUAL FREQUENCY Control. Observe MASTER generated TRMT HZ in right display and DB level received by SLAVE unit in left display at each test frequency. +DB indicates more loss and – DB indicates less loss, relative to the reference frequency.

SLAVE TO MASTER DIRECTION

14. Set REMOTE Switch to SLAVE TO MASTER. Wait until associated dot light illuminates before proceeding. This dot light should come on within 10 seconds. It indicates that the MASTER unit has achieved control over the SLAVE unit.

1000 HZ LOSS MEASUREMENT

15. Observe SLAVE generated by RCV HZ (nominally 1004 Hz) in right display. Observe DBM level received by MASTER unit in left display.

ATTENUATION DISTORTION MEASUREMENT

16. Momentarily hold down LEVEL ZERO Switch. This establishes a 0 dB reference at the reference frequency (1004 Hz).
17. Command SLAVE unit to transmit desired test frequencies by operating MASTER unit TRANSMITTER UP-DOWN Pushbuttons or MANUAL FREQUENCY Control. Observe SLAVE generated RCV HZ in right display and DB level received by MASTER unit in left display at each test frequency. +DB indicates more loss and – DB indicates less loss, relative to the reference frequency.

NOTE

Attenuation Distortion measurements can also be made in absolute dBm. The test set is automatically in the dBm mode until the LEVEL ZERO Switch is operated. To return the test set to the dBm mode, momentarily rotate MEASUREMENT Switch to another position, then back to LEVEL & FREQUENCY again.

C-MESSAGE NOISE MASTER OPERATION




MASTER
SLAVE
MASTER TO SLAVE
MASTER PROVIDES QUIET TERMINATION ACROSS CIRCUIT UNDER TEST. SLAVE MEASURES RECEIVED dBrnC NOISE LEVEL AND TRANSMITS DATA TO MASTER DISPLAY ON OPPOSITE CIRCUIT.
SLAVE TO MASTER
SLAVE PROVIDES QUIET TERMINATION ACROSS CIRCUIT UNDER TEST. MASTER MEASURES AND DISPLAYS RECEIVED dBrnC NOISE LEVEL.
TRMT
M TO S CIRCUIT UNDER TEST
RCV
RCV
S TO M CIRCUIT UNDER TEST
TRMT

C-MESSAGE NOISE MASTER OPERATION

MASTER SETUP

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to LEVEL & FREQUENCY.
3. Set DISPLAY Switch to TRMT.
4. Set TRANSMITTER Switch to STEP 100 HZ.
5. Adjust transmit frequency to 1004 Hz using TRANSMITTER UP-DOWN Pushbuttons. Observe TRMT HZ in right display.
6. Adjust OUTPUT LEVEL Control for "Data Level". Observe DBM level in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Transmission Level Point (TLP). For example, if the TLP is –16 dB, the Data Level would be –29 dBm. Therefore, an output level of –29 dBm would be applied in this case.

7. Set MEASUREMENT Switch to C-MESSAGE NOISE.
8. Set DISPLAY Switch to RCV.
9. Set REMOTE Switch to MASTER.

MASTER TO SLAVE DIRECTION

10. Set REMOTE Switch to MASTER TO SLAVE. Wait until associated dot light illuminates before proceeding. This dot light should come on within 10 seconds. It indicates that the MASTER unit has achieved control over the SLAVE unit. Observe that SLAVE annunciator is on, indicating that measurements will be made by SLAVE unit.
11. Observe DBRNC noise level received by SLAVE unit in left display.

SINGLE FREQUENCY INTERFERENCE CHECK

12. In order to perform a Single Frequency Interference Check in the Master to Slave Direction, the SLAVE unit must turn on his LINE MONITOR by adjusting VOLUME Control until desired loudness is obtained in speaker. He should listen for any predominant tone which will indicate a potential single frequency interference problem.

SLAVE TO MASTER DIRECTION

13. Set REMOTE Switch to SLAVE TO MASTER. Wait until associated dot light illuminates before proceeding. This dot light should come on within 10 seconds. It indicates that the MASTER unit has achieved control over the SLAVE unit.
14. Observe DBRNC noise level received by MASTER unit in left display.

SINGLE FREQUENCY INTERFERENCE CHECK

15. Turn on LINE MONITOR by adjusting VOLUME control until desired loudness is obtained in speaker. Listen for any predominant tone which will indicate a potential single frequency interference problem.

NOISE-WITH-TONE MASTER OPERATION




MASTER
SLAVE
MASTER TO SLAVE
MASTER TRANSMITS 1 kHz TONE ON CIRCUIT UNDER TEST. SLAVE FILTERS OUT 1 kHz TONE, MEASURES RECEIVED dBrnC NOISE LEVEL AND TRANSMITS DATA ON OPPOSITE CIRCUIT TO MASTER DISPLAY.
SLAVE TO MASTER
SLAVE TRANSMITS 1 kHz TONE ON CIRCUIT UNDER TEST. MASTER FILTERS OUT 1 kHz TONE AND MEASURES AND DISPLAYS RECEIVED dBrnC NOISE LEVEL.
TRMT
M TO S CIRCUIT UNDER TEST
RCV
RCV
S TO M CIRCUIT UNDER TEST
TRMT

NOISE-WITH-TONE MASTER OPERATION

MASTER SETUP

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to NOISE-WITH-TONE.
3. Set DISPLAY Switch to TRMT.
4. Observe TRMT HZ in right display. Verify that 1004 Hz is being transmitted.
5. Adjust OUTPUT LEVEL Control for "Data Level". Observe DBM level in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Transmission Level Point (TLP). For example, if the TLP is -16 dB, the Data Level would be -29 dBm. Therefore, an output level of -29 dBm would be applied in this case.

6. Set DISPLAY Switch to RCV.
7. Set REMOTE Switch to MASTER.

MASTER TO SLAVE DIRECTION

8. Set REMOTE Switch to MASTER TO SLAVE. Wait until associated dot light illuminates before proceeding. This dot light should come on within 10 seconds. It indicates that the MASTER unit has achieved control over the SLAVE unit. Observe that SLAVE annunciator is on, indicating that measurements will be made by SLAVE unit.
9. Observe MASTER generated TRMT HZ (1004 Hz) in right display. Observe DBRNC noise level received by SLAVE unit in left display.

SINGLE FREQUENCY INTERFERENCE CHECK

10. In order to perform a Single Frequency Interference Check in the Master to Slave Direction, the SLAVE unit must turn on his LINE MONITOR by adjusting VOLUME Control until desired loudness is obtained in speaker. He should listen for any predominant tone which will indicate a potential single frequency interference problem.

SLAVE TO MASTER DIRECTION

11. Set REMOTE Switch to SLAVE TO MASTER. Wait until associated dot light illuminates before proceeding. This dot light should come on within 10 seconds. It indicates that the MASTER unit has achieved control over the SLAVE unit.
12. Observe SLAVE generated RCV HZ (1004 Hz) in right display. Observe DBRNC noise level received by MASTER unit in left display.

SINGLE FREQUENCY INTERFERENCE CHECK

13. Turn on LINE MONITOR by adjusting VOLUME control until desired loudness is obtained in speaker. Listen for any predominant tone which will indicate a potential single frequency interference problem.

SIGNAL-TO-NOISE MASTER OPERATION




MASTER
SLAVE
MASTER TO SLAVE
MASTER TRANSMITS 1 kHz TONE ON CIRCUIT UNDER TEST. SLAVE ALTERNATELY MEASURES TONE LEVEL AND NOISE LEVEL WITHOUT TONE, CALCULATES RATIO (S+N/N) AND TRANSMITS DATA ON OPPOSITE CIRCUIT TO MASTER DISPLAY.
SLAVE TO MASTER
SLAVE TRANSMITS 1 kHz TONE ON CIRCUIT UNDER TEST. MASTER ALTERNATELY MEASURES TONE LEVEL AND NOISE LEVEL WITHOUT TONE, CALCULATES RATIO (S+N/N) AND DISPLAYS SIGNAL-TO-NOISE RATIO.
TRMT
M TO S CIRCUIT UNDER TEST
RCV
RCV
S TO M CIRCUIT UNDER TEST
TRMT

SIGNAL-TO-NOISE MASTER OPERATION

MASTER SETUP

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to SIGNAL-TO-NOISE.
3. Set DISPLAY Switch to TRMT.
4. Observe TRMT HZ in right display. Verify that 1004 Hz is being transmitted.
5. Adjust OUTPUT LEVEL Control for "Data Level". Observe DBM in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Transmission Level Point (TLP). For example, if the TLP is –16 dB, the Data Level would be –29 dBm. Therefore, an output level of –29 dBm would be applied in this case.

6. Set DISPLAY Switch to RCV.
7. Set REMOTE Switch to MASTER.

MASTER TO SLAVE DIRECTION

8. Set REMOTE Switch to MASTER TO SLAVE. Wait until associated dot light illuminates before proceeding. This dot light should come on within 10 seconds. It indicates that the MASTER unit has achieved control over the SLAVE unit. Observe that SLAVE annunciator is on, indicating that measurements will be made by SLAVE unit.
9. Observe MASTER generated TRMT HZ (1004 Hz) in right display. Observe DB signal-to-noise ratio (S+N/N) received by SLAVE unit in left display.

SLAVE TO MASTER DIRECTION

10. Set REMOTE Switch to SLAVE TO MASTER. Wait until associated dot light illuminates before proceeding. This dot light should come on within 10 seconds. It indicates that the MASTER unit has achieved control over the SLAVE unit.
11. Observe SLAVE generated RCV HZ (1004 Hz) in right display. Observe DB signal-to-noise ratio (S+N/N) received by MASTER unit in left display.

IMPULSE NOISE MASTER OPERATION




MASTER
SLAVE
MASTER TO SLAVE
MASTER TRANSMITS 1 kHz TONE ON CIRCUIT UNDER TEST. SLAVE FILTERS OUT 1 kHz TONE, COUNTS RECEIVED NOISE IMPULSES ABOVE dBrnC THRESHOLD AND TRANSMITS DATA ON OPPOSITE CIRCUIT TO MASTER DISPLAY.
SLAVE TO MASTER
SLAVE TRANSMITS 1 kHz TONE ON CIRCUIT UNDER TEST. MASTER FILTERS OUT 1 kHz TONE, AND COUNTS AND DISPLAYS RECEIVED NOISE IMPULSES ABOVE dBrnC THRESHOLD.
TRMT
M TO S CIRCUIT UNDER TEST
RCV
RCV
S TO M CIRCUIT UNDER TEST
TRMT

IMPULSE NOISE MASTER OPERATION

MASTER SETUP

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to IMPULSE NOISE.
3. Set DISPLAY Switch to TRMT.
4. Observe TRMT HZ in right display. Verify that 1004 Hz is being transmitted.
5. Adjust OUTPUT LEVEL Control for "Data Level". Observe DBM in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Transmission Level Point (TLP). For example, if the TLP is –16 dB, the Data Level would be –29 dBm. Therefore, an output level of –29 dBm would be applied in this case.

6. Set DISPLAY Switch to RCV.
7. Set REMOTE Switch to MASTER.

MASTER TO SLAVE DIRECTION

8. Set REMOTE Switch to MASTER TO SLAVE. Wait until associated dot light illuminates before proceeding. This dot light should come on within 10 seconds. It indicates that the MASTER unit has achieved control over the SLAVE unit. Observe that SLAVE annunciator is on, indicating that measurements will be made by SLAVE unit.
9. Set IMPULSE NOISE Switch to desired count interval (5 MIN, 15 MIN, or NON-STOP).
10. Verify that SLAVE unit IMPULSE NOISE Thumbwheel Switches have been set up to desired DBRNC THRESHOLD. (This should have been performed during his SLAVE SETUP procedure).
11. Momentarily hold down and release IMPULSE NOISE STOP-START/RESET Switch to START/RESET position. Observe that IN PROCESS Annunciator comes on.
12. Left display indicates count time (in minutes) remaining in 5 MIN and 15 MIN modes. Elapsed time is indicated for NON-STOP mode.
13. Observe that IN PROCESS Annunciator goes out at completion of 5 MIN or 15 MIN interval. Observe impulse noise COUNTS received by SLAVE unit on right display.
14. If NON-STOP mode is used, momentarily hold up and release IMPULSE NOISE STOP-START/RESET Switch to STOP position at end of desired counting interval. Observe impulse noise COUNTS received by SLAVE unit in right display.

SINGLE FREQUENCY INTERFERENCE CHECK

15. In order to perform a Single Frequency Interference Check in the Master to Slave Direction, the SLAVE unit must turn on his LINE MONITOR by adjusting VOLUME Control until desired loudness is obtained in speaker. He should listen for any predominant tone which will indicate a potential single frequency interference problem.

(continued on next page)

SLAVE TO MASTER DIRECTION

16. Set REMOTE Switch to SLAVE TO MASTER. Wait until associated dot light illuminates before proceeding. This dot light should come on within 10 seconds. It indicates that the MASTER unit has achieved control over the SLAVE unit.
17. Set IMPULSE NOISE Switch to desired count interval (5 MIN, 15 MIN, or NON-STOP).
18. Set IMPULSE NOISE Thumbwheel Switches to desired DBRNC THRESHOLD.
19. Momentarily hold down and release IMPULSE NOISE STOP-START/RESET Switch to START/RESET position. Observe that IN PROCESS Annunciator comes on.
20. Left display indicates count time (in minutes) remaining in 5 MIN and 15 MIN modes. Elapsed time is indicated for NON-STOP mode.
21. Observe that IN PROCESS Annunciator goes out at completion of 5 MIN or 15 MIN interval. Observe impulse noise COUNTS received by MASTER unit in right display.
22. If NON-STOP mode is used, momentarily hold up and release IMPULSE NOISE STOP-START/RESET Switch to STOP position at end of desired counting interval. Observe impulse noise COUNTS received by MASTER unit in right display.

SINGLE FREQUENCY INTERFERENCE CHECK

23. Turn on LINE MONITOR by adjusting VOLUME Control until desired loudness is obtained in speaker. Listen for any predominant tone which will indicate a potential single frequency interference problem.

NOTE

Count can be reset to zero and restarted at any time by momentarily holding switch to START/RESET position. Count can also be stopped at any time by momentarily holding switch to STOP position, however, count must be restarted at zero counts.

NOTE

The right display has a maximum capacity of 9999 COUNTS. If this capacity is exceeded, the display will indicate "H-12" to indicate "accumulator overflow condition".

NOTE

If a circuit drop-out exceeding one second occurs at any time during the counting interval, a condition code "H-14" will be displayed. If this occurs, it will be necessary to re-establish control over the SLAVE unit by momentarily throwing the REMOTE Switch to NORMAL, then back to MASTER again.

ENVELOPE DELAY MASTER OPERATION




MASTER
SLAVE
MASTER TO SLAVE
MASTER TRANSMITS VARIABLE CARRIER FREQUENCIES (204 Hz – 3904 Hz) MODULATED WITH 83-1/3 Hz ON CIRCUIT UNDER TEST. SLAVE REMODULATES 83-1/3 Hz ON FIXED REFERENCE CARRIER AND TRANSMITS TO MASTER ON RETURN REFERENCE CIRCUIT. MASTER MEASURES AND DISPLAYS ENVELOPE DELAY.
TRMT
CIRCUIT UNDER TEST
RCV
RCV
RETURN REFERENCE CIRCUIT
TRMT


MASTER
SLAVE
SLAVE TO MASTER
MASTER TRANSMITS FIXED REFERENCE CARRIER MODULATED WITH 83-1/3 Hz ON FORWARD REFERENCE CIRCUIT, ALONG WITH COMMAND SIGNALS TO CHANGE SLAVE FREQUENCY. SLAVE REMODULATES 83-1/3 Hz ON VARIABLE CARRIER FREQUENCIES (204 Hz-3904 Hz) AND TRANSMITS TO MASTER ON CIRCUIT UNDER TEST. MASTER MEASURES AND DISPLAYS ENVELOPE DELAY.
TRMT
FORWARD REFERENCE CIRCUIT
RCV
RCV
CIRCUIT UNDER TEST
TRMT

ENVELOPE DELAY MASTER OPERATION

MASTER SETUP

1. Set REMOTE Switch to NORMAL.
2. Set MEASUREMENT Switch to ENVELOPE DELAY.
3. Set DISPLAY Switches to TRMT and LEVEL.
4. Set TRANSMITTER Switch to STEP 100 HZ.
5. If SF signaling units are used in the network under test, set NO SF SKIP – SF SKIP Switch to SF SKIP. This mode automatically blanks the transmitter output so that frequencies between 2450 Hz and 2750 Hz cannot be transmitted.
6. Adjust transmit frequency to reference frequency (e.g., 1804 Hz, or frequency of minimum delay) using TRANSMITTER UP-DOWN Pushbuttons. Observe TRMT HZ in right display.
7. Adjust OUTPUT LEVEL Control for "Data Level". Observe DBM in left display.

DATA LEVEL

All transmission measurements should be made at Data Level. The Data Level for data circuits is a power 13 dB below the Transmission Level Point (TLP). For example, if the TLP is –16 dB, the Data Level would be –29 dBm. Therefore, an output level of –29 dBm would be applied in this case.

8. Set DISPLAY Switch to RCV.
9. Set REMOTE Switch to MASTER.

MASTER TO SLAVE DIRECTION (RETURN REFERENCE)

10. Set REMOTE Switch to MASTER TO SLAVE. Wait until associated dot light illuminates before proceeding. This dot light should come on within 10 seconds. It indicates that the MASTER unit has achieved control over the SLAVE unit. Observe that SLAVE annunciator is on, indicating that measurements will be made by SLAVE unit.
11. Observe ± MICRO SEC in left display. This reading may be very erratic for a few seconds until the loop stabilizes. When the display stabilizes so that only the units and tens digits are changing, momentarily hold down and release DELAY ZERO Switch.

NOTE

This establishes a reference zero at the reference frequency. Typically, this reading will vary ±5 MICRO SEC. However, on very noisy circuits, the variation may be greater. A valid reference zero is established if these variations are evenly distributed above and below zero microseconds.

12. Observe MASTER generated TRMT HZ in right display. Select desired test frequencies using TRANSMITTER UP-DOWN Pushbuttons or MANUAL FREQUENCY Control.
13. At each test frequency, observe ± MICRO SEC envelope delay received by SLAVE unit in left display. If readings vary, observe for an arithmetic mean (average).

SLAVE TO MASTER DIRECTION (FORWARD REFERENCE)

14. Perform MASTER SETUP steps 1-9.
15. Set REMOTE Switch to SLAVE TO MASTER. Wait until associated dot light illuminates before proceeding. This dot light should come on within 10 seconds. It indicates that the MASTER unit has achieved control over the SLAVE unit.
16. Observe ± MICRO SEC in left display. This reading may be very erratic for a few seconds until the loop stabilizes. When the display stabilizes so that only the units and tens digits are changing, momentarily hold down and release DELAY ZERO Switch.

NOTE

This establishes a reference zero at the reference frequency. Typically, this reading will vary ±5 MICRO SEC. However, on very noisy circuits, the variation may be greater. A valid reference zero is established if these variations are evenly distributed above and below zero microseconds.

17. Observe SLAVE generated RCV HZ in right display. Command SLAVE unit to transmit desired test frequencies by operating MASTER unit TRANSMITTER UP-DOWN Pushbuttons or MANUAL FREQUENCY Control.
18. At each test frequency, observe ±MICRO SEC envelope delay received by MASTER unit in left display. If readings vary, observe for an arithmetic mean (average).

HEWLETT hp PACKARD

SALES & SERVICE OFFICES

UNITED STATES

ALABAMA
8290 Whitesburg Dr., S.E.
P.O. Box 4207
Huntsville 35802
Tel: (205) 881-4591
TWX: 810-726-2204

Medical Only
228 W. Valley Ave.,
Room 220
Birmingham 35209
Tel: (205) 942-2081

ARIZONA
2336 E. Magnolia St.
Phoenix 85034
Tel: (602) 244-1361

2424 East Aragon Rd.
Tucson 85706
Tel: (602) 294-3148

***ARKANSAS**
Medical Service Only
P.O. Box 5646
Brady Station
Little Rock 72205
Tel:)501) 664-8773

CALIFORNIA
1430 East Orangethorpe Ave.
Fullerton 92631
Tel: (714) 870-1000

3939 Lankershim Boulevard
North Hollywood 91604
Tel: (213) 877-1282
TWX: 910-499-2170

6305 Arizona Place
Los Angeles 90045
Tel: (213) 649-2511
TWX: 910-328-6147

***Los Angeles**
Tel: (213) 776-7500

3003 Scott Boulevard
Santa Clara 95050
Tel. (408) 249-7000
TWX: 910-338-0518

***Ridgecrest**
Tel: (714) 446-6165

2220 Watt Ave.
Sacramento 95825
Tel: (916) 482-1463

9606 Aero Drive
P.O. Box 23333
San Diego 92123
Tel: (714) 279-3200

COLORADO
5600 South Ulster Parkway
Englewood 80110
Tel: (303) 771-3455

CONNECTICUT
12 Lunar Drive
New Haven 06525
Tel: (203) 389-6551
TWX: 710-465-2029

FLORIDA
P.O. Box 24210
2806 W. Oakland Park Blvd.
Ft. Lauderdale 33307
Tel: (305) 731-2020
TWX: 510-955-4099

***Jacksonville**
Medical Service only
Tel: (904) 725-6333

P.O. Box 13910
6177 Lake Ellenor Dr.
Orlando 32809
Tel: (305) 859-2900
TWX: 810-850-0311

P.O. Box 12826
Pensacola 32575
Tel: (904) 434-3081

GEORGIA
P.O. Box 105005
Atlanta 30348
Tel: (404) 434-4000
TWX: 810-766-4890

Medical Service Only
***Augusta** 30903
Tel: (404) 736-0592

HAWAII
2875 So. King Street
Honolulu 96814
Tel: (808) 955-4455

ILLINOIS
5500 Howard Street
Skokie 60076
Tel: (312) 677-0400
TWX: 910-223-3613

***St. Joseph**
Tel: (217) 469-2133

INDIANA
7301 North Shadeland Ave.
Indianapolis 46250
Tel: (317) 842-1000
TWX: 810-260-1796

IOWA
1902 Broadway
Iowa City 52240
Tel: (319) 338-9466
Night: (319) 338-9467

***KANSAS**
Derby
Tel: (316) 267-3655

KENTUCKY
Medical/Calculator Only
Atkinson Square
3901 Atkinson Dr.,
Suite 207
Louisville 40218
Tel: (502) 456-1573

LOUISIANA
P.O. Box 840
3239 Williams Boulevard
Kenner 70062
Tel: (504) 721-6201
TWX: 810-955-5524

MARYLAND
6707 Whitestone Road
Baltimore 21207
Tel: (301) 944-5400
TWX: 710-862-9157

2 Choke Cherry Road
Rockville 20850
Tel. (301) 948-6370
TWX: 710-828-9684

MASSACHUSETTS
32 Hartwell Ave.
Lexington 02173
Tel: (617) 861-8960
TWX: 710-326-6904

MICHIGAN
23855 Research Drive
Farmington Hills 48024
Tel: (313) 476-6400
TWX: 810-242-2900

MINNESOTA
2400 N. Prior Ave.
Roseville 55113
Tel: (612) 636-0700
TWX: 910-563-3734

MISSISSIPPI
***Jackson**
Medical Service only
Tel: (601) 982-9363

MISSOURI
11131 Colorado Ave.
Kansas City 64137
Tel: (816) 763-8000
TWX: 910-771-2087

148 Weldon Parkway
Maryland Heights 63043
Tel: (314) 567-1455
TWX: 910-764-0830

NEBRASKA
Medical Only
7171 Mercy Road
Suite 110
Omaha 68106
Tel: (402) 392-0948

NEW JERSEY
W. 120 Century Rd.
Paramus 07652
Tel: (201) 265-5000
TWX: 710-990-4951

NEW MEXICO
P.O. Box 11634
Station E
11300 Lomas Blvd., N.E.
Albuquerque 87123
Tel: (505) 292-1330
TWX: 910-989-1185

156 Wyatt Drive
Las Cruces 88001
Tel: (505) 526-2485
TWX: 910-983-0550

NEW YORK
6 Automation Lane
Computer Park
Albany 12205
Tel: (518) 458-1550
TWX: 710-441-8270

New York City
Manhattan, Bronx
Contact Paramus, NJ Office
Tel: (201) 265-5000
Brooklyn, Queens, Richmond
Contact Woodbury, NY Office
Tel: (516) 921-0300

201 South Avenue
Poughkeepsie 12601
Tel: (914) 454-7330
TWX: 510-248-0012

39 Saginaw Drive
Rochester 14623
Tel: (716) 473-9500
TWX: 510-253-5981

5858 East Molloy Road
Syracuse 13211
Tel: (315) 455-2486
TWX: 710-541-0482

1 Crossways Park West
Woodbury 11797
Tel: (516) 921-0300
TWX: 710-990-4951

NORTH CAROLINA
P.O. Box 5188
1923 North Main Street
High Point 27262
Tel: (919) 885-8101
TWX: 510-926-1516

OHIO
16500 Sprague Road
Cleveland 44130
Tel: (216) 243-7300
TWX: 810-423-9431

330 Progress Rd.
Dayton 45449
Tel: (513) 859-8202
TWX: 810-474-2818

1041 Kingsmill Parkway
Columbus 43229
Tel: (614) 436-1041

OKLAHOMA
P.O. Box 32008
Oklahoma City 73132
Tel: (405) 721-0200
TWX: 910-830-6862

OREGON
17890 SW Lower Boones
Ferry Road
Tualatin 97062
Tel: (503) 620-3350

PENNSYLVANIA
111 Zeta Drive
Pittsburgh 15238
Tel: (412) 782-0400
Night: 782-0401
TWX: 710-795-3124

1021 8th Avenue
King of Prussia Industrial Park
King of Prussia 19406
Tel: (215) 265-7000
TWX: 510-660-2670

SOUTH CAROLINA
6941-0 N. Trenholm Road
Columbia 29260
Tel: (803) 782-6493

TENNESSEE
***Memphis**
Medical Service only
Tel: (901) 274-7472

***Nashville**
Medical Service only
Tel: (615) 244-5448

TEXAS
P.O. Box 1270
201 E. Arapaho Rd.
Richardson 75080
Tel: (214) 231-6101
TWX: 910-867-4723

P.O. Box 27409
6300 Westpark Drive
Suite 100
Houston 77027
Tel: (713) 781-6000
TWX: 910-881-2645

205 Billy Mitchell Road
San Antonio 78226
Tel: (512) 434-8241
TWX: 910-871-1170

UTAH
2160 South 3270 West Street
Salt Lake City 84119
Tel: (801) 487-0715

VIRGINIA
Medical Only
P.O. Box 12778
No. 7 Koger Exec. Center
Suite 212
Norfolk 23502
Tel: (804) 497-1026/7

P.O. Box 9854
2914 Hungary Springs Road
Richmond 23228
Tel: (804) 285-3431
TWX: 710-956-0157

WASHINGTON
Bellefield Office Pk.
1203-114th Ave. S.E.
Bellevue 98004
Tel: (206) 454-3971
TWX: 910-443-2446

***WEST VIRGINIA**
Medical/Analytical Only
Charleston
Tel: (304) 345-1640

WISCONSIN
9004 West Lincoln Ave.
West Allis 53227
Tel: (414) 541-0550

FOR U.S. AREAS NOT LISTED:
Contact the regional office nearest you: Atlanta, Georgia... North Hollywood, California... Rockville, Maryland... Skokie, Illinois. Their complete addresses are listed above.

***Service Only**

CANADA

ALBERTA
Hewlett-Packard (Canada) Ltd.
11748 Kingsway Ave.
Edmonton T5G 0X5
Tel: (403) 452-3670
TWX: 610-831-2431 EDTH

Hewlett-Packard (Canada) Ltd.
915-42 Avenue S.E. Suite 102
Calgary T2G 1Z1
Tel: (403) 287-1672
TWX: 610-821-6141

BRITISH COLUMBIA
Hewlett-Packard (Canada) Ltd.
837 E. Cordova Street
Vancouver V6A 3R2
Tel: (604) 254-0531
TWX: 610-922-5059 VCR

MANITOBA
Hewlett-Packard (Canada) Ltd.
513 Century St.
St. James
Winnipeg R3H 0L8
Tel: (204) 786-7581
TWX: 610-671-3531

NOVA SCOTIA
Hewlett-Packard (Canada) Ltd.
800 Windmill Road
P.O. Box 931
Dartmouth B2Y 3Z6
Tel: (902) 469-7820
TWX: 610-271-4482 HFX

ONTARIO
Hewlett-Packard (Canada) Ltd.
1785 Woodward Dr.
Ottawa K2C 0P9
Tel: (613) 225-6530
TWX: 610-562-8968

Hewlett-Packard (Canada) Ltd.
6877 Goreway Drive
Mississauga L4V 1L9
Tel: (416) 678-9430
TWX: 610-492-4246

QUEBEC
Hewlett-Packard (Canada) Ltd.
275 Hymus Blvd.
Pointe Claire H9R 1G7
Tel: (514) 697-4232
TWX: 610-422-3022
TLX: 05-821521 HPCL

Hewlett-Packard (Canada) Ltd.
2376 Galvani Street
Ste-Foy G1N 4G4
Tel: (418) 688-8710
TWX: 610-571-5525

FOR CANADIAN AREAS NOT LISTED:
Contact Hewlett-Packard (Canada) Ltd. in Mississauga.

CENTRAL AND SOUTH AMERICA

ARGENTINA
Hewlett-Packard Argentina
S.A.C.e.I
Lavalle 1171-3° Piso
Buenos Aires
Tel: 35-0436, 35-0627, 35-0341
Telex: Public Booth No. 9
Cable: HEWPACK ARG

BOLIVIA
Stambuk & Mark (Bolivia) Ltda.
Av. Mariscal, Santa Cruz 1342
La Paz
Tel: 40626, 53163, 52421
Telex: 3560014
Cable: BUKMAR

BRAZIL
Hewlett-Packard Do Brasil
I.E.C. Ltda.
Rua Frei Caneca, 1140/52 Bela Vista
01307-**São Paulo**-SP
Tel: 288-71-11, 287-81-20, 287-61-93
Telex: 391-112-3602 HPBR-BR
Cable: HEWPACK São Paulo

Hewlett-Packard Do Brasil
I.E.C. Ltda.
Praca Dom Feliciano, 78-8° andar (Sala 806/8)
90000-**Pôrto Alegre**-RS
Tel: 25-84-70-DDD (0512)
Cable: HEWPACK Pôrto Alegre

Hewlett-Packard Do Brasil
I.E.C. Ltda.
Rua Siqueira Campos, 53, 4° andar-Copacabana
20000-**Rio de Janeiro**-GB
Tel: 257-80-94-DDD (021)
Telex: 391-212-1905 HEWP-BR
Cable: HEWPACK
Rio de Janeiro

CHILE
Calcagni y Metcalfe Ltda.
Alameda 580-Of. 807
Casilla 2118
Santiago, 1
Tel: 398613
Telex: 350001 CALMET
Cable: CALMET Santiago

Medical Only
General Machinery Co., Ltda.
Paraguay 494
Casilla 13910
Santiago
Tel: 31123, 31124
Cable: GEMCO Santiago

COLOMBIA
Instrumentación
Henrik A. Langebaek & Kier S.A.
Carrera 7 No. 48-75
Apartado Aéreo 6287
Bogotá, I.D.E.
Tel: 69-88-77
Cable: AARIS Bogotá
Telex: 044-400

COSTA RICA
Cientifica Costarricense S.A.
Calle Central, Avenidas 1 y 3
Apartado 10159
San José
Tel: 21-86-13
Cable: GALGUR San José

ECUADOR
Medical Only
A.F. Viscaino Compañía Ltda.
Av. Rio Amazonas No. 239
P.O. Box 2925
Quito
Tel: 527-088,527-804
Cable: ASTOR Quito

Calculators Only
Computadoras y Equipos Electrónicos
P.O. Box 2695
Avda. 12 De Octubre No. 2207
Quito
Tel: 233869, 236783
Telex: 02-2113 Sagita Ed
Cable: Sagitra-Quito

EL SALVADOR
IPESA
Bulevar de los Heroes II-48
San Salvador
Tel: 252787

GUATEMALA
IPESA
Avenida La Reforma 3-48, Zona 9
Guatemala City
Tel: 63627, 64786
Telex: 4192 Teletro Gu

MEXICO
Hewlett-Packard Mexicana, S.A. de C.V.
Torres Adalid No. 21, 11° Piso
Col. del Valle
Mexico 12, D.F.
Tel: (905) 543-42-32
Telex: 017-74-507

Hewlett-Packard Mexicana, S.A. de C.V.
Ave. Constitución No. 2184
Monterrey, N.L.
Tel: 48-71-32, 48-71-84
Telex: 038-843

NICARAGUA
Roberto Terán G.
Apartado Postal 689
Edificio Terán
Managua
Tel: 25114, 23412,23454
Cable: ROTERAN Managua

PANAMA
Electrónico Balboa, S.A.
P.O. Box 4929
Calle Samuel Lewis
Cuidad de Panama
Tel: 64-2700
Telex: 3431103 Curunda, Canal Zone
Cable: ELECTRON Panama

PARAGUAY
Z.J. Melamed S.R.L.
División: Aparatos y Equipos Médicos
División: Aparatos y Equipos Cientîficos y de Investigación
P.O. Box 676
Chile-482, Edificio Victoria
Asunción
Tel: 4-5069, 4-6272
Cable: RAMEL

PERU
Compañía Electro Médica S.A.
Los Flamencos 145
San Isidro Casilla 1030
Lima 1
Tel: 413485
Cable: ELMED Lima

PUERTO RICO
Hewlett-Packard Inter-Americas
Puerto Rico Branch Office
P.O. Box 2908I
65th Inf. Station
San Juan 00929
Calle 272, Urb. Country Club
Carolina 00639
Tel: (809) 762-7355/7455/7655
Telex: 3450514

URUGUAY
Pablo Ferrando S.A.
Comercial e Industrial
Avenida Italia 2877
Casilla de Correo 370
Montevideo
Tel. 40-3102
Cable: RADIUM Montevideo

VENEZUELA
Hewlett-Packard de Venezuela C.A.
Apartado 50933, Caracas 105
Edificio Segre
Tercera Transversal
Los Ruices Norte
Caracas 107
Tel. 35-01-07, 35-00-84, 35-00-65, 35-00-3I
Telex: 25146 HEWPACK
Cable: HEWPACK Caracas

FOR AREAS NOT LISTED, CONTACT
Hewlett-Packard
Inter-Americas
3200 Hillview Ave.
Palo Alto, California 94304
Tel. (415) 493-1501
TWX: 910-373-1260
Cable: HEWPACK Palo Alto
Telex: 034-8300, 034-8493

EUROPE

AUSTRIA
Hewlett-Packard Ges.m.b.H.
Handelska 52/3
P.O. Box 7
A-1205 **Vienna**
Tel: (0222) 35 16 21 to 32
Cable: HEWPAK Vienna
Telex: 75923 hewpak a

BELGIUM
Hewlett-Packard Benelux
S.A./N.V.
Avenue de Col-Vert, 1,
(Groenkraaglaan)
B-1170 **Brussels**
Tel: (02) 672 22 40
Cable: PALOBEN Brussels
Telex: 23 494 paloben bru

DENMARK
Hewlett-Packard A/S
Datavej 52
DK-3460 **Birkerod**
Tel: (02) 81 66 40
Cable: HEWPACK AS
Telex: 166 40 hpas

Hewlett-Packard A/S
Naverve 1
DK-8600 **Silkeborg**
Tel: (06) 82 71 66
Telex: 166 40 hpas
Cable: HEWPACK AS

FINLAND
Hewlett-Packard OY
Nahkahousuntie 5
P.O. Box 6
SF-00211 **Helsinki** 21
Tel: 6923031
Cable: HEWPACKOY Helsinki
Telex: 12-1563

FRANCE
Hewlett-Packard France
Quartier de Courtaboeuf
Boite Postale No. 6
F-91401 **Orsay**
Tel: (1) 907 78 25
Cable: HEWPACK Orsay
Telex: 600048

Hewlett-Packard France
"Le Saquin"
Chemin des Mouilles
Boite Postale No. 12
F-69130 **Ecully**
Tel: (78) 33 81 25,
Cable: HEWPACK Eculy
Telex: 310617

Hewlett-Packard France
Agence Régionale
Péricentre de la Cépière
Chemin de la Cépière, 20
F-31300 **Toulouse-Le Mirail**
Tel:(61) 40 11 12
Telex: 510957F

Hewlett-Packard France
Agence Régionale
Aéroport principal de
Marseille-Marignane
F-13721**Marignane**
Tel: (91) 89 12 36
Cable: HEWPACK MARGN
Telex: 410774F

Hewlett-Packard France
Agence Régionale
63, Avenue de Rochester
F-35000 **Rennes**
Tel: (99) 36 33 21
Cable: HEWPACK 74912
Telex: 740912F

Hewlett-Packard France
Agence Régionale
74, Allée de la Robertsau
F-67000 **Strasbourg**
Tel: (88) 35 23 20/21
Telex: 890141
Cable: HEWPACK STRBG

Medical/Calculator Only
Hewlett-Packard France
Agence Régionale
Centre Vauban
201, rue Colbert
Entrée A2
F-59000 **Lille**
Tel: (20) 51 44 14
Telex: 820744

GERMAN FEDERAL REPUBLIC
Hewlett-Packard GmbH
Vertriebszentrale Frankfurt
Bernerstrasse 117
Postfach 560 140
D-6000 **Frankfurt** 56
Tel: (0611) 50 04-1
Cable: HEWPACKSA Frankfurt
Telex: 04 13249 hpFFmd

Hewlett-Packard GmbH
Technisches Buero Böblingen
Herrenbergerstrasse 130
D-7030 **Böblingen**, Württemberg
Tel: (07031) 667-1
Cable: HEPAK Böblingen
Telex: 07265739 bbn

Hewlett-Packard GmbH
Technisches Buero Düsseldorf
Emanuel-Leutze-Str.1 (Seestern)
D-4000 **Düsseldorf**
Tel: (0211) 59711
Telex: 85/86 533 hpdd d

Hewlett-Packard GmbH
Technisches Buero Hamburg
Wendenstrasse 23
D-2000 **Hamburg** 1
Tel: (040) 24 13 93
Cable: HEWPACKSA Hamburg
Telex: 21 63 032 hphh d

Hewlett-Packard GmbH
Technisches Buero Hannover
Mellendorfer Strasse 3
D-3000 **Hannover-Kleefeld**
Tel: (0511) 55 60 46
Telex: 092 3259

Hewlett-Packard GmbH
Technisches Buero Nuremberg
Neumeyer Str. 90
D-8500 **Nuremberg**
Tel: (0911) 56 30 83/85
Telex: 0623 860

Hewlett-Packard GmbH
Technisches Buero München
Unterhachinger Strasse 28
ISAR Center
D-8012 **Ottobrunn**
Tel: (089) 601 30 61/7
Telex: 52 49 85
Cable: HEWPACKSA München
Telex: 0524985

(West Berlin)
Hewlett-Packard GmbH
Technisches Buero Berlin
Keith Strasse 2-4
D-1000 **Berlin** 30
Tel: (030) 24 90 86
Telex: 18 3405 hpbln d

GREECE
Kostas Karayannis
18, Ermou Street
GR-**Athens** 126
Tel: 3237731

Cable: RAKAR Athens
Telex: 21 59 62 rkar gr

Analytical Only
"INTECO" G. Papathanassiou & Co.
Marini 17
GR - **Athens** 103
Tel: 521 915
Cable: INTEKNIKA
Telex: 21 5329 INTE GR

Medical Only
Technomed Hellas Ltd.
52, Skoufa Street
GR - **Athens** 135
Tel: 626 972, 663 930,614 959
Cable: ETALAK Athens
Telex: 21-4693 ETAL GR

ICELAND
Medical Only
Elding Trading Company Inc.
Hafnarhvoli - Tryggvatotu
IS-**Reykjavik**
Tel: 1 58 20
Cable: ELDING Reykjavik

IRAN
Hewlett-Packard Iran Ltd.
Mir-Emad Avenue
14th Street No 19
IR-**Tehran**
Tel: 85 10 82/86

IRELAND
Hewlett-Packard Ltd.
King Street Lane
Winnersh, Wokingham
GB-**Berkshire** RG11 5AR
Tel: (0734) 78 47 74
Telex: 847178/848179

ITALY
Hewlett-Packard Italiana S.p.A.
Casella postale 3645
I-20124 **Milano**
Tel: (2) 6251 (10 lines)
Cable: HEWPACKIT Milano
Telex: 32046

Hewlett-Packard Italiana S.p.A.
Via Pietro Maroncelli 40
(ang. Via Visentin)
I-35100 **Padova**
Tel: (49) 66 48 88
Telex: 32046 via Milano

Medical only
Hewlett-Packard Italiana S.p.A.
Via d'Aghiardi, 7
I-56100 **Pisa**
Tel: (050) 2 32 04
Telex: 32046 via Milano

Hewlett-Packard S.p.A.
Via G. Armellini 10
I-00143 **Roma**-Eur
Tel: (06) 54 69 61
Telex: 61514
Cable: HEWPACKIT Roma

Hewlett-Packard Italiana S.p.A.
Via San Quintino, 46
I-10121 **Turino**
Tel: 53 82 64/54 84 68
Telex: 32046 via Milano

Medical/Calculators Only
Hewlett-Packard Italiana S.p.A.
Via Principe Nicola 43 G/C
I-95126 **Catania**
Tel:(095) 37 05 05

Hewlett-Packard Italiana S.p.A.
Via Amerigo Vespucci, 9
I-80142 **Napoli**
Tel: (81) 33 77 11

Hewlett-Packard Italiana S.p.A.
Via E. Masi, 9/B
I-40137 **Bologna**
Tel: (051) 30 78 87

LUXEMBURG
Hewlett-Packard Benelux
S.A./N.V.
Avenue du Col-Vert, 1,
(Groenkraaglaan)
B-1170 **Brussels**
Tel: (02) 672 22 40
Cable: PALOBEN Brussels
Telex: 23 494

NETHERLANDS
Hewlett-Packard Benelux N.V.
Van Heuven Goedhartlaan 121
P.O. Box 667
NL- **Amstelveen** 1134
Tel: (020) 47 20 21
Cable: PALOBEN Amsterdam
Telex: 13 216 hepa nl

NORWAY
Hewlett-Packard Norge A/S
Nesveien 13
Box 149
N-1344 **Haslum**
Tel: (02) 53 83 60
Telex: 16621 hpnas n

POLAND
BIURO INFORMACJI TECHNICZNEJ
Hewlett-Packard
U1 Stawki 2 6P
00-950**Warsaw**
Tel: 39 67 43
Telex: 81 24 53 hepa pl

PORTUGAL
Telectra-Empresa Técnica de
Equipamentos Eléctricos S.a.r.l.
Rua Rodrigo da Fonseca 103
P.O. Box 2531
P-**Lisbon** 1
Tel: (19) 68 60 72
Cable: TELECTRA Lisbon
Telex: 12598

Mundinter
Intercambio Mundial de Comércio
S.a.r.l.
Av.A.A.de Aguiar 138
P.O. Box 2761
P - **Lisbon**
Tel: (19) 53 21 31/7
Cable: INTERCAMBIO Lisbon

RUMANIA
Hewlett-Packard Technical Office
BD.N. Balcesci 16
Bucharest
Tel: 1580 23/138885
Telex: 10440

SPAIN
Hewlett-Packard Española, S.A.
Jerez No. 3
E-**Madrid** 16
Tel:(1) 458 26 00 (10 lines)
Telex: 23515 hpe

Hewlett-Packard Española, S.A.
Milanesado 21-23
E-**Barcelona** 17
Tel: (3) 203 6200 (5 lines)
Telex: 52603 hpbe e

Hewlett-Packard Española, S.A.
Av Ramón y Cajal 1-9°
(Edificio Sevilla I)
E-**Seville** 5
Tel: 64 44 54/58

Hewlett-Packard española S.A.
Edificio Alhia II 7° B
E-**Bilbao**
Tel: 23 83 06/23 82 06

Calculators Only
Hewlett-Packard Española S.A.
Gran Via Fernando El Católico, 67
E-**Valencia**-8
Tel: 326 67 28/326 85 55

SWEDEN
Hewlett-Packard Sverige AB
Enighetsvägen 3
Fack
S-161 20 **Bromma** 20
Tel: (08) 730 05 50
Cable: MEASUREMENTS
Stockholm
Telex: 10721

Hewlett-Packard Sverige AB
Frotallsgatan 30
S-421 32 **Vastra Frolunda**
Tel: (031) 49 09 50
Telex: 10721 via Bromma Office

SWITZERLAND
Hewlett-Packard (Schweiz) AG
Zürcherstrasse 20
P.O. Box 307
CH-8952 Schlieren **Zurich**
Tel: (01) 98 18 21
Cable: HPAG CH
Telex: 53933 hpag ch

Hewlett-Packard (Schweiz) AG
9, Chemin Louis-Pictet
CH-1214 Vernier-**Geneva**
Tel: (022) 41 49 50
Cable: HEWPACKAG Geneva
Telex: 27 333 hpag ch

TURKEY
Telekom Engineering Bureau
P.O. Box 437
Beyglu
TR-**Istanbul**
Tel: 49 40 40
Cable: TELEMATION Istanbul

UNITED KINGDOM
Hewlett-Packard Ltd.
King Street Lane
GB-**Winnersh**, Wokingham
Berks. RG11 5AR
Tel: (0734) 78 47 74
Cable: Hewpie London
Telex:847178/9

Hewlett-Packard Ltd.
"The Graftons"
Stamford New Road
GB-**Altrincham**
Cheshire WA14 1DJ
Tel: (061) 928 9021
Cable: Hewpie Manchester
Telex: 668068

Hewlett-Packard Ltd.
Lygon Court
Dudley Road
GB-**Halesowen**, Worcs
Tel: (021) 550 7053
Telex: (021) 550 7273

Hewlett-Packard Ltd.
4th Floor
Wedge House
799, London Road
GB-**Thornton Heath** CR4 6XL
Surrey
Tel: (01) 684 0103/0105
Telex: 946825

Hewlett-Packard Ltd.
c/o Makro
South Service Wholesale Centre
Wear Industrial Estate
Washington
GB-**New Town**, County Durham
Tel: Washington 464001 ext. 57/58

Hewlett-Packard Ltd.'s registered
address for V.A.T. purposes
only
70, Finsbury Pavement
GB-**London**, EC2A1SX
Registered No. 690597

USSR
Hewlett-Packard Representative
Office USSR
Pokrovsky Boulevard 4/17, Suite 12
Moscow101000
Tel: 294 2024
Telex: 7825 hewpak SU

YUGOSLAVIA
Iskra-standard/Hewlett-Packard
Office
Miklosiceva 38/VII
61000 **Ljubljana**
Tel: 315-879/321-674
Telex: 31583 YU HEWPAK

AFRICA, ASIA, AUSTRALIA

AMERICAN SAMOA
Calculators Only
Oceanic Systems Inc.
P.O. Box 777
Pago Pago Bayfront Road
Pago Pago 96799
Tel: 633-5513
Cable: OCEANIC-Pago Pago

ANGOLA
Telectra
Empresa Técnica de
Equipamentos
Eléctricos, S.A.R.L.
R. Barbosa Rodrigues, 42-1°DT.°
Caixa Postal, 6487
Luanda
Tel: 35515/6
Cable: TELECTRA Luanda

AUSTRALIA
Hewlett-Packard Australia
Pty. Ltd.
31-41 Joseph Street
Blackburn, Victoria 3130
P.O. Box 36
Doncaster East, Victoria 3109
Tel: 89-6351
Telex: 31-024
Cable: HEWPARD Melbourne

Hewlett-Packard Australia
Pty. Ltd.
31 Bridge Street
Pymble
New South Wales, 2073
Tel: 449-6566
Telex: 21561
Cable: HEWPARD Sydney

Hewlett-Packard Australia
Pty. Ltd.
153 Greenhill Road
Parkside, 5063, S.A.
Tel: 27-2591
Telex: 82536 ADEL
Cable: HEWPARD ADELAIDE

Hewlett-Packard Australia
Pty. Ltd.
141 Stirling Highway
Nedlands, W.A. 6009
Tel: 86-5455
Telex: 93859 PERTH
Cable: HEWPARD PERTH

Hewlett-Packard Australia
Pty. Ltd.
121 Wollongong Street
Fyshwick, A.C.T. 2609
Tel: 95-3733
Telex: 62650 Canberra
Cable: HEWPARD CANBERRA

Hewlett Packard Australia
Pty. Ltd.
5th Floor
Teachers Union Building
495-499 Boundary Street
Spring Hill, 4000 Queensland
Tel: 29-1544
Telex: 42133 BRISBANE

CYPRUS
Kypronics
19 Gregorios & Xenopoulos Rd.
P.O. Box 1152
CY-**Nicosia**
Tel: 45628/29
Cable: KYPRONICS PANDEHIS

GUAM
Medical/Pocket Calculators Only
Guam Medical Suply, Inc.
Jay Ease Building, Room 210
P.O. Box 8383
Tamuning 96911
Tel: 646-4513
Cable: EARMED Guam

HONG KONG
Schmidt & Co.(Hong Kong) Ltd.
P.O. Box 297
Connaught Centre
39th Floor
Connaught Road, Central
Hong Kong
Tel: H-255291-5
Telex: 74766 SCHMC HX
Cable: SCHMIDTCO Hong Kong

INDIA
Blue Star Ltd.
Kastun Buildings
Jamshedji Tata Rd.
Bombay 400 020
Tel: 29 50 21
Telex: 2156
Cable: BLUEFROST

Blue Star Ltd.
Sahas
414/2 Vir Savarkar Marg
Prabhadevi
Bombay 400 025
Tel: 45 78 87
Telex: 4093
Cable: FROSTBLUE

Blue Star Ltd.
Band Box House
Prabhadevi
Bombay 400 025
Tel: 45 73 01
Telex: 3751
Cable: BLUESTAR

Blue Star Ltd.
14/40 Civil Lines
Kanpur 208 001
Tel: 6 88 82
Telex: 292
Cable: BLUESTAR

Blue Star Ltd.
7 Hare Street
P.O. Box 506
Calcutta 700 001
Tel: 23-0131
Telex: 7655
Cable: BLUESTAR

Blue Star Ltd.
Blue Star House
34 Mahatma Gandhi Rd.
Laipatnagar
New Delhi 110 024
Tel: 62 32 76
Telex: 2463
Cable: BLUESTAR

Blue Star Ltd.
Blue Star House
11/11A Magarath Road
Bangalore 560 025
Tel: 55668
Telex: 430
Cable: BLUESTAR

Blue Star Ltd.
Meeakshi Mandiran
xxx/1678 Mahatma Gandhi Rd.
Cochin 682 016 Kerala
Tel: 32069, 70127, 32282
Telex: 046-514
Cable: BLUESTAR

Blue Star Ltd.
1-1-117/1
Sarojini Devi Road
Secunderabad 500 003
Tel: 70126, 70127
Cable: BLUEFROST
Telex: 459

Blue Star Ltd.
23/24 Second Line Beach
Madras 600 001
Tel: 23954
Telex: 379
Cable: BLUESTAR

Blue Star Ltd.
Nathraj Mansions
2nd Floor Bistupur
Jamshedpur 831 001
Tel: 7383
Cable: BLUESTAR
Telex: 240

INDONESIA
BERCA Indonesia P.T.
P.O. Box 496
1st Floor JL. Cikini Raya 61
Jakarta
Tel: 56038, 40369, 49886
Telex: 42895
Cable: BERCACON

BERCA Indonesia P.T.
63 JL. Raya Gubeng
Surabaya
Tel: 44309

IRAN
Hewlett-Packard Iran Ltd.
Mir-Emad Ave.
14th Street, No. 19
IR-**Tehran**
Tel: 851082/86
Telex: 21 25 74

ISRAEL
Electronics & Engineering Div.
of Motorola Israel Ltd.
16 Kremenetski Street
P.O. Box 25016
Tel-Aviv
Tel: 38973
Telex: 33569
Cable: BASTEL Tel-Aviv

JAPAN
Yokogawa-Hewlett-Packard Ltd.
Ohashi Building
1-59-1 Yoyogi
Shibuya-ku, **Tokyo**
Tel: 03-370-2281/92
Telex: 232-2024YHP
Cable: YHPMARKET TOK 23-724

Yokogawa-Hewlett-Packard Ltd.
Nissei Ibaraki Building
2-8 Kasuga 2-chrome, Ibaraki-shi
Osaka 567
Tel: (0726) 23-1641
Telex: 5332-385 YHP OSAKA

Yokogawa-Hewlett-Packard Ltd.
Nakamo Building
24 Kami Sasajima-cho
Nakamura-ku, **Nagoya** , 450
Tel: (052) 571-5171

Yokogawa-Hewlett-Packard Ltd.
Tanigawa Building
2-24-1 Tsuruya-choo
Kanagawa-ku
Yokohama, 221
Tel: 045-312-1252
Telex: 382-3204 YHP YOK

Yokogawa-Hewlett-Packard Ltd.
Mito Mitsui Building
105, 1-chrome, San-no-maru
Mito, Ibaragi 310
Tel.: 0292-25-7470

Yokogawa-Hewlett-Packard Ltd.
Inoue Building
1348-3, Asahi-cho, 1-chome
Atsugi, Kanagawa 243
Tel: 0462-24-0452

KENYA
Technical Engineering
Services(E.A.)Ltd.,
P.O. Box 18311
Nairobi
Tel: 557726/556762
Cable: PROTON

Medical Only
International Aeradio(E.A.)Ltd.,
P.O. Box 19012
Nairobi Airport
Nairobi
Tel: 336055/56
Telex: 22201/22301
Cable: INTAERID Nairobi

KOREA
American Trading Company
Korea
C.P.O. Box 1103
Dae Kyung Bldg., 8th Floor
107 Sejong-Ro,
Chongro-Ku, **Seoul**
Tel: (4 lines) 73-8924-7
Telex: K-28338
Cable: AMTRACO Seoul

LEBANON
Constantin E. Macridis
Clemenceau Street 34
P.O. Box 7213
RL-**Beirut**
Tel: 36 63 97/8
Telex: 21114 Leb
Cable: ELECTRONUCLEAR Beirut

MALAYSIA
Teknik Mutu Sdn. Bhd.
2 Lorong 13/6A
Section 13
Petaling Jaya,**Selangor**
Tel: 773455(5 lines)

MOZAMBIQUE
A.N. Goncalves, Lta.
162, 1° Apt. 14 Av. D. Luis
Caixa Postal 107
Lourenco Marques
Tel: 27091, 27114
Telex: 6-203 Negon Mo
Cable: NEGON

NEW ZEALAND
Hewlett-Packard (N.Z.) Ltd.
4-12 Cruickshank Street
Kilbirnie, Wellington 3
Mailing Address: Hewlett-Packard
(N.Z.) Ltd.
P.O. Box 9443
Courtney Place
Wellington
Tel: 877 199
Telex: NZ 3839
Cable: HEWPACK Wellington

Hewlett-Packard (N.Z.) Ltd.
Pakuranga Professional Centre
267 Pakuranga Highway
Box 51092
Pakuranga
Tel: 569-651
Telex: NZ 3839
Cable: HEWPACK,Auckland

Analytical/Medical Only
Medical Supplies N.Z. Ltd.
Scientific Division
79 Carlton Gore Rd., Newmarket
P.O. Box 1234
Auckland
Tel: 75-289
Telex: 2958 MEDISUP
Cable: DENTAL Auckland

Analytical/Medical Only
Medical Supplies N.Z. Ltd.
P.O. Box 1994
147-161 Tory St.
Wellington
Tel: 850-799
Telex: 3858
Cable: DENTAL, Wellington

Analytical/Medical Only
Medical Supplies N.Z. Ltd.
P.O. Box 309
239 Stanmore Road
Christchurch
Tel: 892-019
Cable: DENTAL, Christchurch

Analytical/Medical Only
Medical Supplies N.Z. Ltd.
303 Great King Street
P.O. Box 233
Dunedin
Tel: 88-817
Cable: DENTAL, Dunedin

NIGERIA
The Electronics
Instrumentations Ltd.
N6B/770 Oyo Road
Oluseun House
P.M.B. 5402
Ibadan
Tel: 61577
Telex: 31231 TEIL Nigeria
Cable: THETEIL Ibadan

The Electronics instrumenta-
tions Ltd.
144 Agege Motor Road, Mushin
P.O. Box 6645
Lagos
Cable: THETEIL Lagos

PAKISTAN
Mushko & Company, Ltd.
Oosman Chambers
Abdullah Haroon Road
Karachi-3
Tel: 511027, 512927
Telex: KR894
Cable: COOPERATOR Karachi

Mushko & Company, Ltd.
38B, Satellite Town
Rawalpindi
Tel: 41924
Cable: FEMUS Rawalpindi

PHILIPPINES
The Online Advanced Systems
Corporation
6th Floor, Yujuico Building
560 Quintin Paredes Street
Binondo, **Manila**
Tel: 40-05-41, 40-05-31
Telex: 3327 GENBANK

RHODESIA
Field Technical Sales
45 Kelvin Road North
P.O. Box 3458
Salisbury
Tel: 705231 (5 lines)
Telex: RH 4122

SINGAPORE
Hewlett-Packard Singapore
(Pte.) Ltd.
Blk. 2, 6th Floor, Jalan
Bukit Merah
Redhill Industrial Estate
Alexandra P.O. Box 58,
Singapore 3
Tel: 633022
Telex: HPSG RS 21486
Cable: HEWPACK, Singapore

SOUTH AFRICA
Hewlett-Packard South Africa
(Pty.) Ltd.
Private Bag Wendywood
Sandton, Transvaal 2144
Hewlett-Packard House
Daphne Street, Wendywood,
Sandton, Transvaal 2144
Tel: 802-104016
Telex: SA43-4782JH
Cable: HEWPACK JOHANNESBURG

Hewlett-Packard South Africa
(Pty.) Ltd.
P.O. Box 120
Howard Place, Cape Province,
7450
Pine Park Center, Forest Drive,
Pinelands, Cape Province, 7405
Tel: 53-7955 thu 9
Telex: 57-0006

Hewlett-Packard South Africa
(Pty.) Ltd.
P.O. Box 37099
Overport, Durban 4067
641 Ridge Road, Durban
Durban, 4001
Tel: 88-7478,88-1080,88-2520
Telex: 6-7954
Cable: HEWPACK

TAIWAN
Hewlett-Packard Far East Ltd.,
Taiwan Branch
39 Chung Shiao West Road
Sec. 1, 7th Floor
Taipei
Tel: 389160,1,2,3
Telex: 21824 HEWPACK
Cable: HEWPACK TAIPEI

Hewlett-Packard Taiwan
38, Po-Ai Lane, San Min Chu,
Kaohsiung
Tel: (07) 242318

Analytical Only
San Kwang Instruments Co., Ltd.,
No. 20, yung Sui Road
Taipei, 100
Tel: 3713171-4
Telex: 22894 SANKWANG
Cable: SANKWANG TAIPEI

TANZANIA
Medical Only
International Aeradio (E.A.), Ltd.
P.O. Box 861
Daressaisam
Tel: 21251 Ext. 265
Telex: 41030

THAILAND
UNIMESA Co., Ltd.
Elcom Research Building
Bangjak Sukumvit Ave.
Bangkok
Tel: 932387, 930338
Cable: UNIMESA Bangkok

UGANDA
Medical Only
International Aeradio(E.A.), Ltd.,
P.O. Box 2577
Kampala
Tel: 54388
Cable: INTAERIO Kampala

ZAMBIA
R.J. Tilbury (Zambia) Ltd.
P.O. Box 2792
Lusaka
Tel: 73733
Cable: ARJAYTEE, Lusaka

MEDITERRANEAN AND MIDDLE EAST COUNTRIES NOT SHOWN PLEASE CONTACT:
Hewlett-Packard S.A.
Mediterranean and Middle
East Operations
35, Kolokotroni Street
Platia Kefallariou
GR-Kifissia-**Athens**
Tel: 21-6584
Cable: HEWPACKSA Athens

OTHER AREAS NOT LISTED, CONTACT:
Hewlett-Packard Intercontinental
3200 Hillview Ave.
Palo Alto, California 94304
Tel: (415) 493-1501
TWX: 910-373-1267
Cable: HEWPACK Palo Alto
Telex: 034-8300, 034-8493

HEWLETT hp PACKARD

MP MASTER
MA24854

04942-90001

Printed in U.S.A.